




OPERATOR'S MANUAL

MOBILE ELEVATING WORK PLATFORM
A45E

EN - 9841/8967 ISSUE 3 - 07/2024

THIS MANUAL SHOULD ALWAYS STAY WITH THE MACHINE



OPERATOR'S MANUAL

MOBILE ELEVATING WORK PLATFORM
A45E

EN - 9841/8967 - ISSUE 3 - 07/2024

This manual contains original instructions, verified by
the manufacturer (or their authorized representative).

Copyright 2024 © JCB SERVICE
All rights reserved. No part of this publication may
be reproduced, stored in a retrieval system, or
transmitted in any form or by any other means,
electronic, mechanical, photocopying or otherwise,
without prior permission from JCB SERVICE.

www.jcb.com

Foreword

The Operator's Manual



You and others can be killed or seriously injured if you operate or maintain the machine without first studying the Operator's Manual. You must understand and follow the instructions in the Operator's Manual. If you do not understand anything, ask your employer or JCB dealer to explain it.

Do not operate the machine without an Operator's Manual, or if there is anything on the machine you do not understand.

Treat the Operator's Manual as part of the machine. Keep it clean and in good condition. Replace the Operator's Manual immediately if it is lost, damaged or becomes unreadable.

California Proposition 65

▲ WARNING Diesel engine exhaust and some of its constituents are known to the State of California to cause cancer, birth defects, and other reproductive harm.

Machine Delivery and Installation

Even if you have operated this type of equipment before, it is very important that your new machines operations and functions are explained to you by a JCB Dealer Representative following delivery of your new machine.

Following the installation you will know how to gain maximum productivity and performance from your new product.

Please contact your local JCB dealer if the Installation Form (included in this manual) has not yet been completed with you.

Your local JCB Dealer is



This image shows a blank sheet of white paper with horizontal ruling lines. The lines are evenly spaced and run across the width of the page. There are no margins, text, or other markings on the paper.

Contents	Page No.
Acronyms Glossary	v
Introduction	
About this Manual	
Model and Serial Number	1
Using the Manual	1
Left-Hand Side, Right-Hand Side	1
Cross References	2
Location of Manual	2
Safety	
Safety - Yours and Others	3
Safety Warnings	3
General Safety	3
Clothing and Personal Protective Equipment (PPE)	4
About the Product	
Introduction	
General	5
Name and Address of the Manufacturer	5
Product Compliance	5
Description	
General	6
Intended Use	6
Log Moving/Object Handling	6
Danger Zone	6
Main Component Locations	7
Product and Component Identification	
Machine	8
Safety Labels	
General	9
Safety Label Identification	9
Operation	
Introduction	
General	11
Operating Safety	
General	12
Worksite Safety	13
Risk Assessment	13
Walk-Around Inspection	
General	15
Entering and Leaving the Platform	
General	16
Service Disconnect	
General	18
Starting the Machine	
General	20
Stopping and Parking	
General	21
Instruments	
Instrument Panel	22



Getting the Machine Moving	
General	26
Slopes	
General	28
Driving on Slopes	28
Driving the Machine	
General	32
Operating Levers/Pedals	
Basic Controls	34
Working with the Platform	
General	35
Moving a Disabled Machine	
General	38
Lifting the Product	
General	41
Lifting Points	42
Transporting the Product	
General	44
Loading onto the Transporting Vehicle	44
Tie Down Points	45
Operating Environment	
General	46
Operating in Low Temperatures	46
Operating in High Temperatures	46
Preservation and Storage	
Cleaning	
General	47
Storage	
General	49
Put into Storage	49
During Storage	49
Take out of Storage	50
Maintenance	
Introduction	
General	51
Owner/Operator Support	51
Service/Maintenance Agreements	52
Obtaining Spare Parts	52
Maintenance Safety	
General	53
Fluids and Lubricants	53
Maintenance Schedules	
General	57
How to Use the Maintenance Schedules	57
Maintenance Intervals	57
Operator Maintenance Tasks	57
Service Engineer Maintenance Tasks	59
Maintenance Positions	
General	62

Service Points	
General	63
Access Apertures	
General	64
Battery Cover	64
Hydraulic Compartment Cover	65
Front Cover	65
Rear Cover	66
Body and Framework	
General	68
Controls	
Check (Operation)	69
Safety Equipment	
Check (Operation)	74
Brakes	
General	78
Steering System	
General	79
Tires	
General	80
Hydraulic System	
Oil	81
Electrical System	
General	82
Battery	83
Service Disconnect	87
Fuses	87
Relays	89
Technical Data	
Introduction	
General	93
Static Dimensions	
Dimensions	94
Weights	95
Visibility Diagrams	96
Performance Dimensions	
General	99
Boom Dimensions and Performance	101
Noise Emissions	
Noise Data	102
Vibration Emissions	
Vibration Data	103
Fluids, Lubricants and Capacities	
General	104
Torque Values	
General	105
Electrical System	
General	106
Fuses	106
Relays	108
Batteries	109



Hydraulic System	
General	110
Wheels and Tires	
General	111
Fault-Finding	
General	112
Warranty Information	
Service Record Sheet	113

Acronyms Glossary

AC	Alternating Current
DC	Direct Current
ECU	Electronic Control Unit
LED	Light Emitting Diode
MEWP	Mobile Elevating Work Platform
PIN	Product Identification Number
PPE	Personal Protective Equipment
RCBO	Residual Current Breaker with Over-Current



Notes:

Introduction

About this Manual

Model and Serial Number

This manual provides information for the following model(s) in the JCB machine range:

Table 1.

Model	VIN Prefix.
A45E	RAJA4054
	RAJA4154
	RAJA4A54
	RAJA4B54

Using the Manual

The Quick Start Guide or Quick Reference Guide (if supplied) with the machine does not replace the Operator's Manual. You must read all the disclaimers and safety instructions in the Operator's Manual before initially operating the machine.

This Operator's Manual is arranged to give you a good understanding of the machine and its safe operation. It also contains maintenance and technical data.

Read this manual from the front to the back before you use the machine for the first time, even if you have used machines of a similar/same type before as the technical specification, systems and controls of the machine may have changed. Particular attention must be given to all the safety aspects of operating and maintaining the machine.

If there is anything you are not sure about, ask your JCB dealer or employer. Do not guess, you or others could be killed or seriously injured.

The general and specific warnings in this section are repeated throughout the manual. Read all the safety statements regularly, so you do not forget them. Remember that the best operators are the safest operators.

The illustrations in this manual are for guidance only. Where the machines are different, the text and / or the illustration will specify.

The manufacturer's policy is one of continuous improvement. The right to change the specification of the machine without notice is reserved. No responsibility will be accepted for discrepancies which may occur between specifications of the machine and the descriptions contained in this manual.


All the optional equipment included in this manual may not be available in all territories.

Left-Hand Side, Right-Hand Side

In this manual, 'left' and 'right' mean your left and right when you are stood in the platform facing the platform control.

[Refer to: Main Component Locations \(Page 7\).](#)

Figure 1.



A Right side

B Left side

C Platform control

Cross References

In this manual, cross references are made by presenting the subject title in blue (electronic copy only). The number of the page upon which the subject begins is indicated within the brackets. For example:
[Refer to: Cross References \(Page 2\)](#).

Location of Manual

The operator's manual is kept in to a 'document box' in the center of platform under the controls. The manual should always be put back in its box after use.

Safety

Safety - Yours and Others

All machinery can be hazardous. When a machine is correctly operated and maintained, it is a safe machine to work with. When it is carelessly operated or poorly maintained it can become a danger to you (the operator) and others.

In this manual and on the machine you will find warning messages, you must read and understand them. They inform you of potential hazards and how to avoid them. If you do not fully understand the warning messages, ask your employer or JCB dealer to explain them.

Safety is not just a matter of responding to the warnings. All the time you are working on or with the machine you must be thinking of what hazards there might be and how to avoid them.

Do not work with the machine until you are sure that you can control it.

Do not start any work until you are sure that you and those around you will be safe.

If you are not sure of anything, about the machine or the work, ask someone who knows. Do not assume anything.

Remember:

- Be careful.
- Be alert.
- Be safe.

Safety Warnings

In this manual there are safety notices. Each notice starts with a signal word. The signal word meanings are given below.

The signal word 'DANGER' indicates a hazardous situation which, if not avoided, will result in death or serious injury.

The signal word 'WARNING' indicates a hazardous situation which, if not avoided, could result in death or serious injury.

The signal word 'CAUTION' indicates a hazardous situation which, if not avoided, could result in minor or moderate injury.

The signal word 'Notice' indicates a hazardous situation which, if not avoided, could result in machine damage.

The safety alert system symbol (shown) also helps to identify important safety messages in this manual. When you see this symbol your safety is involved, carefully read the message that follows.

Figure 2. The safety alert system symbol



General Safety

Training

To operate the machine safely you must have received the appropriate training. The operator's manual instructs you on the machine, its controls and its safe operation; it is not a training manual. Ensure that you receive the correct training before operating the machine. Failure to do so will result in incorrect operation of the machine and you will be putting yourself and others at risk. You must abide by all local site regulations. Make sure that you and your machine comply with relevant local laws and jobsite requirements – it is your responsibility.

Care and Alertness

All the time you are working with or on the machine, take care and stay alert.

Alcohol and Drugs

It is extremely dangerous to operate machinery when under the influence of alcohol or drugs. Do not consume alcoholic drinks or take drugs before or while operating the machine or attachments. Be aware of medicines which can cause drowsiness.

Feeling Unwell

Do not attempt to operate the machine if you are feeling unwell. By doing so you could be a danger to yourself and those you work with.

Hillsides

Operating the machine on hillsides can be dangerous if the correct precautions are not taken. Ground conditions can be changed by rain, snow, ice etc. Check the site carefully. When applicable, keep all attachments low to the ground.

Cell Phones

Switch off your cell phone before entering an area with a potentially explosive atmosphere. Sparks in such an area could cause an explosion or fire resulting in death or serious injury.

Raised Equipment

Never walk or work under raised equipment unless it is supported by a mechanical device. Equipment which is supported only by a hydraulic device can drop and injure you if the hydraulic system fails or if the control is operated (even with the motor stopped).

Make sure that no-one goes near the machine while you install or remove the mechanical device.

Raised Machine

Never position yourself or any part of your body under a raised machine which is not correctly supported. If the machine moves unexpectedly you could become trapped and suffer serious injury or be killed.

Lightning

Lightning can kill you. Do not use the machine if there is lightning in your area.

Machine Modifications

This machine is manufactured in compliance with prevailing legislative requirements. It must not be altered in any way which could affect or invalidate its compliance. For advice consult your JCB dealer.

Clothing and Personal Protective Equipment (PPE)

Do not wear loose clothing that can get caught on controls or moving or rotating machine parts. Keep cuffs fastened. Do not wear a necktie or scarf. Keep long hair restrained. Remove rings, watches and personal jewelry. Wear protective clothing and personal safety equipment issued or called for by the job conditions, local regulations or as specified by your employer. It is recommended to put on safety harnesses at all times when operating the machine.

About the Product

Introduction

General

Before you start using the machine, you must know how the machine operates. Use this part of the manual to identify each control lever, switch, gage, button and pedal. Do not guess. If there is anything you do not understand, ask your JCB dealer.

Name and Address of the Manufacturer

JCB Access Limited, Lakeside Works, Rocester, Uttoxeter, United Kingdom, ST14 5JP.

Product Compliance

Your JCB product was designed to comply with the laws and regulations applicable at the time of its manufacture for the market in which it was first sold. In many markets, laws and regulations exist that require the owner to maintain the product at a level of compliance relevant to the product when first produced. Even in the absence of defined requirements for the product owner, JCB recommend that the product compliance be maintained to ensure safety of the operator and exposed persons and to ensure the correct environmental performance. Your product must not be altered in any way which could affect or invalidate any of these requirements. For advice consult your JCB dealer.

For its compliance as a new product, your JCB and some of its components may bear approval numbers and markings, and may have been supplied with a Declaration/Certificate of Conformity. These markings and documents are relevant only for the country/region in which the product was first sold to the extent that the laws and regulations required them.

Re-sales and import/export of products across territories with different laws and regulations can cause new requirements to become relevant for which the product was not originally designed or specified. In some cases, pre owned products irrespective of their age are considered new for the purposes of compliance and may be required to meet the latest requirements which could present an insurmountable barrier to their sale/use.

Despite the presence of any compliance related markings on the product and components, you should not assume that compliance in a new market will be possible. In many cases it is the person responsible for import of a pre owned product into a market that becomes responsible for compliance and who is also considered the manufacturer.

JCB may be unable to support any product compliance related enquiry for a product which has been moved out of the legislative country/region where it was first sold, and in particular where a product specification change or additional certification would have been required in order for the product to be in compliance.

Description

General

Important Note: This equipment is compliant with Class A of CISPR16/EN55016 and may cause interference in excess of limits required in residential areas.

This machine is a self propelled MEWP (Mobile Elevating Work Platform) with a wheeled undercarriage. A articulated and telescopic boom is mounted to a revolving upper structure.

Intended Use

The machine is intended to lift personnel with their tools, and position them at a level of working height safely. The machine can be used to reach areas located above machinery or equipment positioned at ground level by use of the extending structure and platform.

The machine is intended to be used for the applications and in the environmental conditions as described in this manual. Use in any other way not described in the manual is considered contrary to intended use of this machine.

The machine is not intended for use in mining and quarrying applications, in demolition activities, forestry, any use underground, or in any kind of explosive atmosphere. This is not an exhaustive list. For any activity not described here, it is recommended that a risk assessment must be done prior to operation.

If the machine is to be used in applications where there is a high silica concentration, risk due to materials containing asbestos or similar hazards, additional protective measures such as the use of PPE (Personal Protective Equipment) may be required.

The machine should not be operated by any person who does not have an appropriate level of qualification, training or experience of use of this type of machine.

Prior to use of the machine, its suitability (size, performance, specification etc.) should be considered with regards to the intended application and any relevant hazards that may exist. Contact your JCB dealer for support in determining the appropriate JCB machine, attachment and any optional equipment that is suitable for the application and environment.

The machine is not intended to be used as a towing machine. Do not attach trailers or other towing devices to the machine.

Log Moving/Object Handling

Do not use the machine to move or handle logs or other objects. You could cause serious injury to yourself and damage to the machine. Do not use the machine as a crane. Do not overload the platform with tools or equipment.

[Refer to: Technical Data \(Page 93\).](#) For more information, contact your JCB dealer.

Danger Zone


The danger zone is any zone within and/or around the machinery in which a person is subject to a risk to their health or safety. During operation of the machine, keep all persons out of the danger zone. Persons in the danger zone could be injured.

Before you do a maintenance task, make the product safe.

[Refer to: Maintenance Positions \(Page 62\).](#)

Main Component Locations

Figure 3.



- A** Right side canopy
- C** Lower leveling cylinder
- E** Jib
- G** Battery compartment
- J** Jib lift cylinder
- L** Telescopic boom lift cylinder
- N** Base control panel
- Q** Front axle
- S** Secondary guarding system
- U** Foot pedal switch
- W** Oscillating axle cylinder
- Y** Upper leveling cylinder
- AA** Battery isolator
- AC** Beacon
- AE** Telescopic boom (stage 2)
- AG** Boom rear knuckle


- B** Articulated boom
- D** Telescopic boom (stage 1)
- F** Platform controller
- H** Platform entry gate
- K** Control side canopy
- M** Articulated boom lift cylinder
- P** Under carriage
- R** Counter weight
- T** Safety harness anchorage point
- V** Documents box
- X** Platform rotate actuator
- Z** Drag chain
- AB** Battery charging point
- AD** Load cell
- AF** Boom front knuckle
- AH** Platform carrier

Product and Component Identification

Machine

Your machine has an identification plate as shown. [Refer to Figure 4.](#)

Figure 4.



A Machine identification plate

Explanation of Machine Identification Plate

Figure 5.




Table 2.

A	Manufacturers address
B	Regional certification mark (if applicable)
C	PIN (Product Identification Number) ISO10261
D	Model
E	Model and manufacture year (if applicable)
F	Model data
G	Product description and relevant design standards
H	Part number

Safety Labels

General

⚠ WARNING Safety labels on the machine warn you of particular hazards. You can be injured if you do not obey the safety instructions shown.

The safety labels are strategically placed around the machine to remind you of possible hazards.

If you need eye-glasses for reading, make sure you wear them when reading the safety labels. Do not over-stretch or put yourself in dangerous positions to read the safety labels. If you do not understand the hazard shown on the safety label, then refer to Safety Label Identification.

Keep all of the safety labels clean and readable. Replace a lost or damaged safety label. Make sure the replacement parts include the safety labels where necessary. Each safety label has a part number printed on it, use this number to order a new safety label from your JCB dealer.

Safety Label Identification

Figure 6.




Figure 7.




Table 2. Safety Labels

Item	Part No.	Description	Qty.
A	400/D1430	Wear safety harness.	2
B	400/U5049	(Combination label) Warning - Crush hazard (to feet). Keep a safe distance. The attachment may roll forward when released. The object may fall over from the platform.	2
C	817/70112	Warning. Crushing of whole body. Keep a safe distance.	3
D	400/V1939	(Combination label) Warning - Read the Operator's Manual before you operate the machine. Warning - Electrical hazard. Stay a safe distance away from power lines. Warning - Operate the decent alarm when you lower the boom. Follow the correct sequence while lowering the boom.	1
E	400/V1418	(Combination label) Warning - Pressure hazard. Stop the machine, remove the ignition key and consult service manual before carrying out any servicing and maintenance work. Caution - Burns to fingers and hands. Stay a safe distance away. Warning - Explosion hazard. Remove sources of ignition.	1
F	817/70106	Warning. Strike to whole body (machine swing). Keep a safe distance from the machine.	2
G	332/P7124	Strike. Keep clear of the reversing machine.	2
H	817/70110	Warning. Crushing of whole body. Keep a safe distance from machine.	1
J	817/70032	Electrical hazard. Read the Operator's Manual.	8

Operation

Introduction

General

The aim of this part of the manual is to guide the operator step-by-step through the task of learning how to operate the machine efficiently and safely. Read the "Operation" section thoroughly from beginning to end.

The operator must always be aware of events happening in or around the machine. Safety must always be the most important factor when you operate the machine.

When you understand the operating controls, gages and switches, practice using them. Drive the machine in an open space, clear of people. Get to know the 'feel' of the machine and its driving controls.

Do not rush the job of learning, make sure you fully understand everything in the "Operation" section. Take your time and work efficiently and safely.

Remember:

- Be careful.
- Be alert.
- Be safe.

Operating Safety

General

Training

Make sure that you have had adequate training and that you are confident in your ability to operate the machine safely before you use it. Practice using the machine and its attachments until you are completely familiar with the controls and what they do. Where applicable you may be required to show competency to a national certification scheme. Ensure you comply with local legislation and jobsite rules. With a careful, well trained and experienced operator, your machine is a safe and efficient machine. With an inexperienced or careless operator, it can be dangerous. Do not put your life, or the lives of others, at risk by using the machine irresponsibly. Before you start to work, tell your colleagues what you will be doing and where you will be working. On a busy site, use a signalman.

Before doing any job not covered in this manual, find out the correct procedure. Your local JCB distributor will be glad to advise you.

Machine Condition

A defective machine can injure you or others. Do not operate a machine which is defective or has missing parts. Make sure the maintenance procedures in this manual are completed before using the machine.

Machine Limits

Operating the machine beyond its design limits can damage the machine, it can also be dangerous. Do not operate the machine outside its limits. Do not try to upgrade the machine performance with unapproved modifications or additional equipment.

Communications

Bad communications can cause accidents. Keep people around you informed of what you will be doing. If you will be working with other people, make sure any hand signals that may be used are understood by everybody. Worksites can be noisy, do not rely on spoken commands.

You must stop the machine operation, isolate the controls and turn off the machine when persons are required to interact with it.

Parking

An incorrectly parked machine can move without an operator. Follow the instructions in the Operator's Manual to park the machine correctly.

Banks and Trenches

Banked material and trenches can collapse. Do not work or drive too close to banks and trenches where there is danger of collapse.

Safety Barriers

Unguarded machines in public places can be dangerous. In public places, or where your visibility is reduced, place barriers around the work area to keep people away.

Sparks

Explosions and fire can be caused by sparks from the exhaust or the electrical system. Do not use the machine in closed areas where there is flammable material, vapor or dust.

Regulations

Obey all laws, worksite and local regulations which affect you and your machine.

Electrical Power Cables

You could be electrocuted or badly burned if you get the machine or its attachments too close to electrical power cables.

You are strongly advised to make sure that the safety arrangements on site comply with the local laws and regulations concerning work near electric power lines.

Before you start using the machine, check with your electricity supplier if there are any buried power cables on the site.

There is a minimum clearance required for working beneath overhead power cables. You must obtain details from your local electricity supplier.

Machine Safety

Stop work at once if a fault develops. Abnormal sounds and smells can be signs of trouble. Examine and repair before resuming work.

Traveling at High Speeds

Traveling at high speeds can cause accidents. Always travel at a safe speed to suit working conditions.

Traveling at Height

If it is not part of the work task, lower the platform before traveling. Only travel at height if it is necessary and the travel area has been inspected.

Confined Areas

Pay extra attention to proximity hazards when operating in confined areas. Proximity hazards include buildings, traffic and bystanders.

Safe Working Loads

Overloading the machine can damage it and make it unstable. Study the specifications in the Operator's Manual before using the machine.

Lightning

If there is lightning, stay away from the machine and do not use the machine. If you are on the machine, exit the machine and get to safety. Do not attempt to mount or enter the machine.

If the machine is struck by lightning do not use the machine until it has been checked for damage and malfunction by trained personnel.

Tools and Objects

Do not cover the platform sides or carry objects with a large surface area when operating outdoors.

Worksite Safety

"Workplace Inspection" will help operators to determine whether the workplace is suitable for operation. Operators must inspect the workplace before they move machines there. It is the operator's responsibility to understand and keep in mind the hazards in the workplace. He/she must pay attention and avoid these problems when moving, installing and operating the machine. Check for hazards such as but not limited to:

- Drop-offs, or potholes including those concealed by water mud, etc.
- Slopes.
- Bumps and floor obstructions.
- Debris.
- Overhead obstructions and electrical conductors.
- Hazardous locations and atmospheres.
- Inadequate surface and support to withstand all load forces imposed by the platform in all operating configurations.
- Wind and weather conditions.
- Presence of unauthorized persons.
- Other possible unsafe conditions.
- Underground utilities and pipes.
- Overhanging objects, tree branches.

Risk Assessment

It is the responsibility of the competent people that plan the work and operate the machine to make a judgement about the safe use of the machine, they must take into account the specific application and conditions of use at the time.

It is essential that a risk assessment of the work to be done is completed and that the operator obeys any safety precautions that the assessment identifies.

If you are unsure of the suitability of the machine for a specific task, contact your JCB dealer who will be pleased to advise you.

The following considerations are intended as suggestions of some of the factors to be taken into account when a risk assessment is made. Other factors may need to be considered.

A good risk assessment depends on the training and experience of the operator. Do not put your life or the lives of others at risk.

Personnel

- Are all persons who will take part in the operation sufficiently trained, experienced and competent? Are they fit and sufficiently rested? A sick or tired operator is a dangerous operator.
- Is supervision needed? Is the supervisor sufficiently trained and experienced?
- As well as the machine operator, are any assistants or lookouts needed?

The Machine

- Is it in good working order?
- Have any reported defects been corrected?
- Have the daily checks been carried out?
- Are the tires in good condition?

Working Area

- Is it level?
- Is the ground solid? Will it support the weight of the machine when loaded?
- How rough is the ground? Are there any sharp projections which could cause damage, particularly to the tires?
- Are there any obstacles or hazards in the area, for example, debris, excavations, manhole covers, power lines?
- Is the space sufficient for safe maneuvering?
- Are any other machines or persons likely to be in or to enter the area while operations are in progress?

The Route to be Traveled

- How solid is the ground, will it provide sufficient traction and braking? Soft ground will affect the stability of the machine and this must be taken into account.
- How steep are any slopes, up/down/across? A cross slope is particularly hazardous, is it possible to detour to avoid them?

Weather

- How windy is it? High wind will adversely affect the stability of a loaded machine.
[Refer to: Performance Dimensions \(Page 99\).](#)
- Is it raining or is rain likely? The ground that was solid and smooth when dry will become uneven and slippery when wet, and it will not give the same conditions for traction, steering or braking.

Emergency Plan

Make sure that an emergency rescue plan is in place and understood by those involved when operating the machine from the platform controller at height. It is important to make sure that those involved in the rescue plan are aware of the location of the lowering controls and how to operate the machine.

Walk-Around Inspection

General

▲ DANGER Check the brackets in the center of the wheel hubs to ensure they are in their normal extruded position before leaving or operating the machine. Otherwise there is a risk that the machine will roll away.

[Refer to: General \(Page 26\).](#)

The machine walk-around or pre-operation inspection is an important routine task and must be performed by the operator. This is a visual inspection that must be performed by the operator before using the machine. If there are any issues observed during inspection, then machine maintenance is required.

[Refer to: Maintenance Schedules \(Page 57\).](#)

The following checks must be made each time you return to the machine after leaving it for any period of time. We advise you also to stop the machine occasionally during long work sessions and do the checks again.

All these checks concern the serviceability of the machine. Some concern your safety. Get your service engineer to check and correct any defects.

1. Check for cleanliness.
 - 1.1. Remove dirt and debris, especially from around the linkages, rams, pivot points.
 - 1.2. Make sure the platform floor and handrails are clean and dry.
 - 1.3. Clean all of the safety and instructional labels. Replace any label that is missing or cannot be read.
2. Check for damage.
 - 2.1. Examine the machine generally for damaged and missing parts.
 - 2.2. Make sure that all of the fasteners and pivot pins are correctly installed.
 - 2.3. Check the operation of the platform side rails.
 - 2.4. Check the condition of the tires.
 - 2.5. Check for leaks
3. Make sure that all of the access panels are closed correctly.
 - 3.1. If access panels are installed with locks, we recommend that you lock them to prevent theft or tampering.
4. Check condition of safety harness anchorage points. Check the condition after any excessive loading.
5. Check the brackets in the center of the wheel hubs to ensure they are in their normal extruded position before leaving or operating the machine. Otherwise there is a risk that the machine will roll away.
[Refer to: General \(Page 38\).](#)
6. Check the operation of all controls.
7. Check the operator's manual is in good condition and is kept in the operator's manual storage compartment.
8. Check the level of the hydraulic fluid and for leaks.
9. Check the condition of the batteries, cables and wiring.
10. Check the operation of the safety equipment.
[Refer to: Check \(Operation\) \(Page 74\).](#)
11. Before operating the boom and drive functions remove the slew lock by positioning the slew lock pin in the unlock position.

Entering and Leaving the Platform

General

▲ CAUTION Entering or leaving the operator station must only be made where handrails are provided. Always face the machine when entering and leaving. Make sure the handrails and your boot soles are clean and dry. Do not jump from the machine. Do not use the machine controls as handholds, use the handrails.

Make sure the machine is stopped, correctly parked and fully stowed before entering or leaving the platform.
[Refer to: Stopping and Parking \(Page 21\).](#)

When entering and leaving the platform always maintain three points of contact. Three points of contact means that two hands and one foot or one hand and two feet are in contact with platform or ground at all times. Do not use the machine controls as handholds.

Before entering and leaving the platform, make sure that the platform is fully lowered.


Entering the Platform

1. Move and hold the slider tube in upward direction. [Refer to Figure 8.](#)
2. Step into the platform.
3. Move the slider tube to its original position.

Leaving the Platform

1. Park the machine on solid, firm, level ground.
2. Move and hold the slider tube in upward direction. [Refer to Figure 8.](#)
3. Step out from the platform.
4. Move the slider tube to its original position. [Refer to Figure 8.](#)

Figure 8.



A Sliding tubes
C Handrail

B Guardrails

Service Disconnect


General

▲ WARNING The batteries remain live even when the isolator key is removed.

Disconnect the Machine Electrics:

1. Turn the key switch to the off position.
2. Get access to the battery isolator.
[Refer to: Service Points \(Page 63\).](#)
3. Disconnect the battery isolator.

Figure 9.



A Isolator switch


Connect the Machine Electrics:

1. Make sure the key switch is at off position.
2. Connect the battery isolator.

Ignition Key

1. Key is removable only in OFF position.
2. When ignition key and isolator both are at ON position, high voltage DC (Direct Current) power is connected.
3. When ignition key is at 'ON' and isolator is at 'OFF' position, high voltage DC power is disconnected.
4. If the ignition key is at 'OFF' position but the isolator is at 'ON' position, then DC power is connected to busbars.


Figure 10.



A Ignition switch

B Ignition key

Figure 11.



A Battery compartment (DC power source)
C Busbar cover

B Battery isolator

Starting the Machine

General

1. Make the machine safe.
[Refer to: Maintenance Positions \(Page 62\).](#)
2. Make sure that both the emergency stop switches at the base and platform control panel are released.
3. Make sure that the canopies, bus bar cover, change over box and battery pods are securely covered and locked.
4. Turn ON the isolator switch and then turn the ignition key switch to the ON position.
[Refer to: Service Disconnect \(Page 18\).](#)
5. All machine operations can be performed from the base and platform control panel.

Note: The machine does not have high torque and low torque modes.

Stopping and Parking

General

The machine uses an electronic park brake in all four wheel motors.

The park brakes release automatically during travel and steer. The park brakes do not release during lifting.

1. Select a safe place to stop where the ground is firm and level such as slabbed or paved surface, where the machine will not cause an obstruction and away from heavy traffic.
2. Lower the platform to stowed position.
3. Rotate the turntable to secure the boom between the non steer wheels.
4. Turn the key switch to the off position. Remove the key to avoid unauthorized use.

Brake Operational Limits

The machine is capable of stopping from its maximum speed on the maximum gradients as stated in this manual.

It is recommended that the machine is not parked or left unattended on slopes greater than those specified in this manual. It is the responsibility of the operator to assess the ground and atmospheric conditions before using or parking the machine on gradients.

The machine must be immediately taken out of service until corrected if the park brakes do not operate within specifications or performance requirements as defined in this manual or any other in-service, periodic or post maintenance brake verification.

Instruments

Instrument Panel


⚠ CAUTION Keep the machine controls clean and dry. Your hands and feet could slide off slippery controls. If that happens you could lose control of the machine.

There are two control panels, one is located on the left side of the machine base, the other is in the operator platform.

Base Control Panel

⚠ WARNING Do not operate the machine with the base control when there are personnel in the platform except in an emergency.

Figure 12.



- | | |
|--|---|
| A Base control panel display | B Key switch |
| C Emergency stop button | D Horn button |
| E Not used | F Emergency override switch |
| G Base control enable switch | H Main boom raise / lower switch |
| J Telescopic boom extend / retract switch | K Jib raise / lower switch |
| L Platform level switch | M Platform rotate switch |
| N Articulated boom raise / lower switch | P Slew left / right switch |

Base Control Display

Figure 13.




Table 3.


Callout	Indicator	Description
A	Date	Displays current date.
B	Time	Displays current time.
C	Machine hour	Displays machine running hours.
D	Display settings	Displays settings for the display.
E	Machine settings	Displays locked screen for new settings of machine.
F	Base information	Displays base information of machine like input, output and machine information.
G	Platform information	Displays platform input/output information.
H	Faults	Displays live and historic faults.
J	Battery voltage warning	Displays when battery voltage is high/low.
K	Powertrain fault lamp	Displays when there is a fault on the powertrain.
L	Tilt limit exceeded	Displays when machine tilt limit is exceeded. Solid lamp if the machine is stowed. Flashing lamp if the machine is raised.
M	Secondary guarding	Displays when the platform secondary guarding is in active condition.
N	Emergency override	Displays when emergency override has been activated.
P	Fault indicator	Displays when there is a fault on the machine.
Q	Machine stowed position	Displays when machine is in stowed position.
R	Machine raised position	Displays when machine is in raised position.
S	Battery level indicator	Displays the battery level in percentage.
T	Power utilization	Displays the power utilization.
U	Overload lamp	Displays when the platform load limit is exceeded. Solid lamp if the load is approaching the limit. Flashing lamp if the load is above the limit.

Callout	Indicator	Description
V	Load management indicator	Displays the amount of load machine is carrying in percentage.
W	Operator error or caution alarm	Displays when machine is operated outside the limits.

Platform Control Panel

⚠ WARNING Do not drive the machine with the platform raised except on smooth, firm and level surface free of obstructions and pot holes.

Figure 14.



- | | |
|--|--|
| A Work lights ON / OFF button | B Error indicator |
| C Platform control panel display | D Emergency stop button |
| E Slew acknowledgment button | F Slew acknowledgment indicator |
| G Auxiliary power button | H Drive and steer joystick |
| J Speed control switch | K Manual platform level switch |
| L Platform rotate switch | M Jib boom up / down switch |
| N Telescopic boom extend / retract switch | P Articulated boom raise / lower switch |
| Q Main boom lift and slew joystick | R Horn button |
| S Not used | T Not used |
| U Not used | |

Platform Control Display

Figure 15.




Table 4.

Callout	Indicator	Description
A	Date	Displays current date.
B	Time	Displays current time.
C	Machine hours	Displays machine running hours.
D	Power utilization gage	Displays the power utilization.
E	Load management indicator	Displays the amount of load machine is carrying in percentage.
F	ECO mode	Displays if ECO mode is enabled
G	Fault indicator display	Displays fault indicators.
H	Operator error or caution alarm	Appears when machine is operated outside the limits.
J	Battery charging level	Displays the battery level in percentage.

Getting the Machine Moving

General

▲ **WARNING** Watch for obstructions around machine and overhead when driving. Check clearance above, to sides, at bottom of machine when lifting or lowering the platform.

WARNING Do not operate the machine from the platform to release the platform when it is stuck, snagged or caught. In this case, use the base control only when there are no persons on the platform.


DANGER Check the brackets in the center of the wheel hubs to ensure they are in their normal extruded position before leaving or operating the machine. Otherwise there is a risk that the machine will roll away.

Perform the pre-operation checks before using the machine.

Refer to: [Check \(Operation\) \(Page 69\)](#).

Disengage the slew lock pin. [Refer to Figure 16](#).

Figure 16.



A Slew lock pin

Raising and Lowering the Platform

Operation from Base

1. Turn the key switch to the ON position.
2. Make sure the base and platform emergency stop buttons are released and there are no faults or alarms active on the machine.
3. Push and hold the base control enable switch, followed by the relevant function switch to raise or lower the platform in the required direction.

[Refer to: Instrument Panel \(Page 22\)](#).

4. When operating the platform, an amber beacon will flash and a white noise alarm will sound at the chassis to draw the attention of nearby persons to keep a safe distance from the machine as booms and platform are operating.

Drive and steer functions are not available from the base controls.

Operation from the Platform

1. Make sure the base and platform emergency stop buttons are released and there are no faults or alarms active on the machine.
2. Push and hold the foot pedal and relevant function switch or joystick / lever in the desired direction to raise or lower the platform.

3. When operating the platform, an amber beacon will flash and a white noise alarm will sound at the chassis to draw the attention of nearby persons to keep a safe distance from the machine as booms and platform are operating.
4. Turn the potentiometer to set the desired speed.

With the travel speed potentiometer at its minimum position it is possible that some services may not move when operated from the platform control panel. Make sure to adjust the travel speed potentiometer for smooth movement.

Multi-functions

When operating the boom controls, some functions may not be permitted simultaneously. In this case, the operation commanded first will be prioritized. To indicate that an operation is not permitted, the operator caution icon will be shown on the base and platform control panel displays. To find out more information about which operations are not permitted simultaneously on your machine, contact your local JCB dealer.

Slopes

General

- ▲ **WARNING** Make sure that you have been trained and are familiar with the use of machines on slopes, and understand the adverse effects that slopes and site conditions can have on stability. Never use the machine on a slope if you do not understand the recommended practices for the use of machines in such applications.

There are a number of factors which can adversely affect the stability of the machine and the safety of the machine and operator when used on a slope.

It is essential that a risk assessment of the work to be done is completed and that the operator complies with any safety precautions that the assessment identifies.

Machine can be driven both in reverse and forward direction.

Driving on Slopes

- ▲ **WARNING** If the tilt indicator warning light/alarm is activated while driving with platform raised, lower the platform and drive to a smooth firm level surface.

WARNING Make sure that the platform is fully stowed while driving the machine on slopes and gradient, otherwise it may affect the stability of the machine.

Understand the uphill, downhill and side slope ratings for the machine and determine the grade of the slope. Do not use the machine on the slope if the rating is exceeded.

Slope rating is subject to ground conditions and adequate traction. The term gradability applies to the machine when it is in the stowed position only.

Make sure that while driving on slopes with the platform fully stowed, the front/back and side slope does not exceed the rated gradient for the machine.

While driving on a slope, reduce the travel speed by turning the potentiometer counterclockwise to a minimum position.


Platform in Stowed Condition

Downhill Slope

Maximum slope rating, platform downhill (gradability):

40% (22°)

Figure 17.




Uphill Slope

Maximum slope rating, platform uphill:

40% (22°)

Figure 18.




Side Slope

Maximum side slope rating:

25% (14°)

Figure 19.



Platform in Raised/Partial Raised Condition

Make sure that while driving on slopes with the platform raised, front/back slope and side slope does not exceed the 5° in all orientations.

Figure 20. Side Slope





Figure 21. Front or Back Slope



Driving the Machine

General

▲ WARNING Do not operate the machine from the platform to release the platform when it is stuck, snagged or caught. In this case, use the base control only when there are no persons on the platform.

WARNING Watch for obstructions around machine and overhead when driving. Check clearance above, to sides, at bottom of machine when lifting or lowering the platform.

Altitude

The machine shall only be operated at an altitude up to 1,000m (1,093½yd) above mean sea level.

Operation from Base

1. Drive and steer functions are not available on the base control.

Operation from Platform

1. Release both base and platform emergency stop buttons.


To Steer

1. Press down the foot pedal switch.
2. Press the steering switch left or right to change the steering direction of the steering wheels according to the markings on the control panel.

[Refer to: Basic Controls \(Page 34\).](#)

Use the color-coded direction arrows on the platform controls and the chassis to identify the direction the wheels will turn.

Figure 22.



To Drive

1. Turn the potentiometer clockwise or counterclockwise to select travel speed.
2. While driving on a slope, reduce the travel speed by turning the potentiometer counterclockwise to a minimum position.
3. Press down the foot pedal to enable the platform control.
4. Move the travel joystick to forward or reverse direction to move.
5. Release the joystick to stop the machine.


Use the color-coded direction arrows on the platform controls and the chassis to identify the direction the wheels will turn.

If the foot pedal is pushed for more than 10 seconds with no operation, it will time-out. The foot pedal should be released and pushed again to enable movements again.

Machine travel speed is reduced when the main boom or articulated boom is raised above their respective lower limit switches, or when the telescopic boom is extended beyond its retract limit switch. If maximum drive speed is necessary, it is recommended to fully stow the main boom and articulated boom. Refer to the main boom, articulated boom and telescopic boom switch position limits.

Slew Acknowledge

Figure 23.



1. If the turntable is slewed more than the specified angle from the forward position (between the non-steer wheels), drive and steer functions will not be available until the operator acknowledges the slew orientation. Angle: +/- 55 degree.
2. The slew position indicator LED (Light Emitting Diode) will flash.
3. Press down the foot pedal switch.
4. Press the slew acknowledge button located below the slew position indicator LED to acknowledge the slew orientation.
5. The slew position indicator LED will change to a constant light.
6. The drive and steer functions will be enabled until the foot pedal switch is released.


Multi-functions

When operating the drive controls, some boom functions may not be permitted simultaneously. In this case, the operation commanded first will be prioritized. The indication that an operation is not permitted is the operator caution icon/LED will lit at the base and platform control panels. To find out more information about which operations are not permitted simultaneously on your machine, contact your local JCB dealer.


Operating Levers/Pedals

Basic Controls

Main Boom Lift and Slew Joystick



Drive and Steer Joystick



Working with the Platform

General

Trip and Fall Hazards

- Prior to operation, make sure that all operator door and guard rails are fastened and secured in their proper position.
- It is recommended that all persons in the platform wear full body harnesses with a short lanyard attached to an authorized lanyard anchor point while operating this machine. For further information refer to JCB dealer.
- Keep both feet firmly on the platform floor at all times. Never position ladders, boxes, steps, planks or other similar items on unit to provide additional reach for any purpose.
- Never use the boom assembly to enter or leave the platform.
- Use extreme caution when entering or leaving platform. Make sure that the boom is fully lowered. It may be necessary to telescope out to position the platform closer to the ground for entering or leaving. Face the machine, maintain “three point contact” with the machine, using two hands and one foot or two feet and one hand during entering and leaving.
- Keep your footwear and the platform floor clean of oil, mud and slippery substances.

Electrocution Hazards

- This machine is not insulated and does not provide protection from contact or proximity to electrical conductors.
- Maintain distance from electrical conductors, apparatus, or any energized (exposed or insulated) parts according to the Minimum Approach Distance. [Refer to Table 5.](#)
- When determining the safe distance, think of machine movement and electrical line swaying.
- The minimum approach distance may be reduced if insulating barriers are installed to prevent contact, and the barriers are rated for the voltage of the line being guarded. These barriers shall not be part of (or attached to) the machine. The minimum approach distance shall be reduced to a distance within the designed working dimensions of the insulating barrier. This determination shall be made by a qualified person in accordance with the employer, local, or governmental requirements for work practices near energized equipment.

Table 5. Minimum Approach Distance

Voltage Range	Minimum Approach Distance
0–50,000V	3m (3½yd)
50,000–200,000V	5m (5½yd)
200,000–350,000V	6m (6½yd)
350,000–500,000V	8m (8½yd)
500,000–750,000V	11m (12yd)
750,000–1,000,000V	14m (15½yd)

Tipping Hazards

- Make sure that the ground conditions are adequate to support the maximum tire load indicated on the tire load decals located on the chassis adjacent to each wheel. Do not travel on unsupported surfaces.
- The user must be familiar with the driving surface before driving. Do not exceed the allowable sideslope and grade while driving.
- Do not raise the platform or drive with platform raised while on or near a sloping, uneven, or soft surface. Make sure that the machine is positioned on the level, solid (slabbed or paved) ground before elevating platform or driving with the platform in the elevated position.
- Before driving on floors, bridges, trucks, and other surfaces, check allowable capacity of the surfaces.
- Never exceed the maximum work load as specified on the platform. Keep all loads within the confines of the platform. Evenly distribute the load across the platform, or the machine could become unstable.
- Keep the chassis of the machine suitably away from holes, bumps, drop-offs, obstructions, debris, concealed holes, and other potential hazards on the floor/surface.
- Do not push or pull any object with the boom.
- Do not operate the machine when wind conditions exceed the limit.
- Never attempt to use the machine as a crane. Do not tie-off machine to any adjacent structure. Never attach wire, cable, or any similar item to platform.

- If the platform or booms becomes stuck or snagged on an adjacent or overhead structure, do not try to free the machine until all personnel are removed from the platform.
- Do not increase the surface area of the platform or the load. Increase of the area exposed to the wind will decrease the stability.
- Do not increase platform size with unauthorized deck extensions or attachments.
- Do not raise the platform with the access apertures open. Keep the access apertures closed whilst the platform is raised.
- If the boom assembly or platform is caught so that one or more wheels are off the ground, all the persons and tools must be removed before attempting to stabilize the machine. Use a crane, forklift truck, or other appropriate equipment to stabilize the machine.

Crushing and Collision Hazards

- Approved head protection must be worn by all operating and ground personnel.
- Watch for obstructions around machine and overhead when driving. Check clearance above, to sides, at bottom of machine when lifting or lowering the platform.
- During operation, keep all body parts inside platform railing.
- Use the boom functions, not the drive function, to position the platform close to obstacles.
- Always post a lookout when driving in areas where vision is obstructed.
- Keep non-operating personnel at least 1.8m (2yd) (71 inches) away from machine during all operations.
- Under all travel conditions, the operator must limit travel speed according to conditions of ground surface, congestion, visibility, slope, location of personnel, and other factors.
- Be aware of stopping distances in all drive speeds. Travel on slope or grades in low speed only.
- Do not use high speed drive in restricted or close quarters.
- Exercise extreme caution at all times to prevent obstacles from striking or interfering with operating controls and persons in the platform.
- Make sure that operators of other overhead and floor level machines are aware of the aerial work platform's presence. Position barriers around the floor if necessary.
- Do not operate over ground personnel. Warn personnel not to work, stand, or walk under a raised platform. Position barriers on floor as necessary.

Platform Information Decals

The decals are located below the platform control box.

Figure 26. Decal Description




Table 6.

Items	Description
A	Warning. Keep a safe distance from the overhead electrical cables.
B	Warning. Read operator's manual before operating the machine.
C	Warning. Do not exit the platform at height. Do not walk or climb on the booms.
D	Warning. In the event of a stability hazard, lower the platform in the order shown, depending on the orientation of the machine on the slope.
E	Maximum manual force
F	Maximum wind speed
G	Maximum rated load on the platform
H	Maximum platform height

Moving a Disabled Machine

General

▲ **WARNING** Do not use the platform controller to release the platform when it is stuck, snagged or caught. In this case, use the ground controller only when there are no persons on the platform.

Notice: Following any incident, thoroughly inspect the machine. Do not raise the platform until you are sure that all damage has been repaired and that all controls are operating correctly. Test all functions first from the ground controller, then from the platform controller.

The operator can lower the platform in the event of an emergency.

Boom functions may be powered by the auxiliary battery. This method of operation is intended for recovering a disabled machine in the event that operation from the main batteries is not possible.

If the machine becomes disabled, the machine must be made safe, lifted onto a transporter and moved to a location where it can be repaired.

Towing, winching or pushing the machine without following the correct procedure may damage parts of the machine. If possible, repair the disabled machine where it stands.

Lower the Platform

Powerpack malfunction (Battery low, short circuit etc).

Operation From the Base Control

1. Pull out the emergency stop button.
2. Press and hold the selection switch to base control position.
3. Continue to hold the selection switch, so that the machine can operate from the ground position and activate the desired boom function.

Operation From the Platform Control

1. Pull out the emergency stop button.
2. Press down the foot pedal switch.
3. Select the auxiliary power on/ off button and activate the desired boom function.

Lower the Platform (Emergency Operation)

Override control must be used in the event of an emergency only. A service engineer should be called to reset the emergency override display alert triggered by using base override. If the override control has been used because the platform has been overloaded, the machine should be inspected for any structural damage, and the overload system should be re-calibrated according to the instructions in the service manual. This override should not be used to intentionally lift or lower loads heavier than the maximum rated platform load. If the platform is overloaded, the excess weight must be removed from the platform before lowering the platform. When override is used, the booms should be operated in order to return the machine to a safe working condition.

Operation From the Base Control

1. Turn the ignition key to the off position.
2. Pull out the emergency stop button.
3. Press and hold the red emergency override button.
4. Turn the ignition key to the on position.
5. Caution light will flash and a buzzer will beep from both control positions. The ground control display will indicate "emergency override" condition has been activated.
6. Continue to hold the red emergency override button and activate the desired boom function.

Operation From the Platform Control

1. Press the foot pedal switch and keep it pressed.
2. Press and hold the AUX button.
 - 2.1. The engine will stop automatically if it's running and an 'Emergency Override Active' message will appear on the display.
 - 2.2. The machine alarm will sound for 2s and mute for 2s.
3. Continue to hold the emergency override button and operate the desired boom function.
4. Release the AUX button.
 - 4.1. Now, the normal machine operation can be resumed.

Emergency Stop System

The machine have an emergency stop at both base and platform control panels. When either of the emergency stop is pressed, it prevents engine start.

Emergency Stop from Base Control Panel

1. When the base emergency stop button is pressed, it stops the power supply to the machine (i.e. displays etc.).
[Refer to: Basic Controls \(Page 34\).](#)
2. When the base emergency stop is pressed, it cannot be overridden by the base override.
3. When the base emergency stop button is released/unpressed, make sure that all the desired functions work correctly.

Emergency Stop from Platform Control Panel

1. When the platform emergency stop button is pressed, it stops the power supply to the machine (i.e. displays etc.).
[Refer to: Basic Controls \(Page 34\).](#)
2. When the platform emergency stop is pressed, it can be overridden by the base override.
3. When the platform emergency stop button is released/unpressed, make sure that all the desired functions work correctly.

Manual Brake Deactivation

▲ WARNING Do not keep the brake deactivated for a duration more that 30 minutes. Before towing the machine perform a risk assessment and make sure there is a safe method of stopping the machine since the machine brakes will not be available.


Manual brake deactivation is required when there is machine failure and the machine needs to be towed to a safe maintenance site. Do not tow the machine for a distance more than 200m. Before towing make sure that the oil level in the hub is appropriate.

Make a note that after towing operation install the disengage cap in its original position on all four hubs.

1. Make the machine safe.
[Refer to: Safety \(Page 3\).](#)
2. Remove the screw (x2).
3. Remove the disengage cap from the hub.
4. Flip the disengage cap and install to the hub.

5. Tighten the screw (x2).
6. Repeat steps 1 to 5 to other hubs.

Figure 27.



- | | |
|---|--|
| A Disengage cap | B Disengage cap (brake disengaged position) |
| C Disengage cap (brake engaged position) | D Screw (x2) |

Lifting the Product

General

Lifting points are provided for lifting the machine. Using these points will give a safe stable lift. Other methods of lifting are not recommended.

[Refer to: Lifting Points \(Page 42\).](#)

Lifting Procedure

1. Make the machine safe with the platform lowered.
2. Remove any loose items from the machine.
3. Make sure all the access covers and canopies are securely shut.
4. Use an appropriate length of lifting equipment to prevent damage to the platform base and guardrail.
5. Make sure the hoist rigging is in the correct position. Adjust the hoist rigging to prevent machine damage and keep the machine in the level position.

- 5.1. You must consider the location of the center of gravity on the machine, when you lift the machine. The center of gravity is located at a point on the ground, at the center of front axle.


[Refer to: Lifting Points \(Page 42\).](#)

- 5.2. Use foam to protect the booms and counterweight at suitable contact points to avoid damage.

The machine should be in the fully stowed position in 0° slewing position and in the forward drive position. If necessary, slew the machine to 5° which will let the vertical chains lift the machine without impacting the boom structure.

Lifting Points

Figure 28.



A Spreader bars
C Lifting points

B Lifting chains

Figure 29.




Table 7. Location of the Center of Gravity

X- axis	Y- axis	Z- axis
1,104mm (43½in)	1,064mm (42in)	1,095.5mm (43in)

Transporting the Product

General

▲ WARNING The safe transit of the load is the responsibility of the transport contractor and driver. Any machine, attachments or parts that may move during transit must be adequately secured.

CAUTION Before moving the machine onto the trailer, make sure that the trailer and ramp are free from oil, grease and ice. Remove oil, grease and ice from the machine tires. Make sure the machine will not foul on the ramp angle.

Check the condition of the transport vehicle before the machine is loaded on to its trailer.

Make sure that the transport trailer is suitable for the dimensions and weight of your machine.


Before transporting the machine make sure you will be obeying the local rules and laws regarding machine transportation of all the areas that the machine will be carried through.

Loading onto the Transporting Vehicle

Lifting the Machine onto the Transporting Vehicle/Trailer

1. Place the boom and jib in the stowed position.
2. Turn off the machine and remove the key.
3. Remove any loose items from the machine.
4. Engage the slew lock pin. [Refer to Figure 30.](#)

Figure 30.



A Slew lock pin

5. Place the wheel chocks at the front and rear of the trailer wheels.
6. Lift the machine on to the trailer.
7. Put wheel choke blocks at the front and rear of all four wheels. Make sure they are securely in place.
8. Measure the maximum height of the machine from the ground. Total height should comply with regulations for transportation. Make sure the truck driver knows the clearance height before he drives away.
9. Secure the chassis to the trailer bed with suitable restraint. Use the tie down points indicated by the safety decals.
[Refer to: Tie Down Points \(Page 45\).](#)
10. Secure the platform with strap placed over the platform mount near the platform rotator. The platform should rest on a block during transportation. Do not use excessive downward force when securing the boom section.


Refer to: Tie Down Points (Page 45).

Driving the Machine onto the Transporting Vehicle/Trailer

1. Put the blocks at the front and rear of the trailer wheels.
2. Lower the ramps and check for suitability. Ramp should be with less than 40% gradient.
Refer to: Performance Dimensions (Page 99).
3. Make sure that the machine load distribution is correct.
Refer to: General (Page 32).
4. Put wheel chock blocks at the front and rear of all four wheels. Make sure they are secured in place.
5. Turn the machine off and remove the key.
6. Remove any loose items from the machine.
7. Engage the slew lock pin. Refer to Figure 30.
8. Measure the maximum height of the machine from the ground. Make sure the truck driver knows the clearance height before he drives away.
9. Secure the machine to the trailer bed with suitable restraint. Use the tie down points indicated by the decals.
Refer to: Tie Down Points (Page 45).


Tie Down Points

Figure 31.



A Tie down decal

Figure 32.



Operating Environment

General

In low and high temperature conditions, take the following precautions. This will prevent possible damage to your machine.

Operating in Low Temperatures

1. Use the correct grade of hydraulic oil.
[Refer to: Fluids, Lubricants and Capacities \(Page 104\).](#)
2. Keep all the battery at full charge.
3. Protect the machine when its not in use. Park the machine inside a building or cover it with a tarpaulin.

Operating in High Temperatures

1. Keep the hydraulic oil / fluid at the correct level. Make sure there are no leaks.
2. Use the correct grade of hydraulic oil.
[Refer to: Fluids, Lubricants and Capacities \(Page 104\).](#)
3. Check the air vents. Make sure that the air vents to and from the battery compartment are not blocked.
4. Keep all the battery at full charge.

Preservation and Storage Cleaning

General

▲ **WARNING** When using cleaning agents, solvents or other chemicals, you must adhere to the manufacturer's instructions and safety precautions.

WARNING Airborne particles of light combustible material such as straw, grass, wood shavings, etc. must not be allowed to accumulate within the battery compartment. Examine these areas frequently and clean at the beginning of each work shift or more often if required. Before opening the battery cover, make sure that the top is clear of debris.

CAUTION To avoid burning, wear personal protective equipment when handling hot components. To protect your eyes, wear goggles when using a brush to clean components.

Notice: Cleaning metal parts with incorrect solvents can cause corrosion. Use only recommended cleaning agents and solvents.

Notice: The efficiency of the rams will be affected if they are not kept free of solidified dirt. Clean dirt from around the rams regularly. When leaving or parking the machine, close all rams if possible to reduce the risk of weather corrosion.

Notice: Never use water or steam to clean the platform controls. The use of water or steam could damage the machine electrics and render the machine inoperable. Remove dirt using a brush or damp cloth.

Clean the machine with water and/or steam. Do not allow mud, debris etc. to collect on the machine.

Before you do any service procedures that require components to be removed:

- The cleaning must be done either in the area of components to be removed, or in the case of major work, the whole machine must be cleaned.
- When cleaning is complete, move the machine away from the wash area or alternatively, remove the material washed from the machine.

When you remove components, be aware of exposure to dirt and debris. Cover any open ports and remove the deposits before proceeding.

Refer to the individual clean procedures throughout the Maintenance section.

[Refer to: Maintenance Schedules \(Page 57\).](#)

Detergents

Do not use a full strength detergent. Always dilute the detergents as per the manufacturer's recommendations, or damage to the paint finish can occur.

Always obey the local regulations regarding the disposal of debris created from cleaning the machine.

Pressure Washing and Steam Cleaning

▲ **CAUTION** When using a steam cleaner, wear safety glasses or a face shield as well as protective clothing. Steam can cause personal injury.

Notice: The battery and other electrical components could be damaged by high pressure washing systems. Special precautions must be taken if the machine is to be washed using a high pressure system.

During pressure jet wash keep all the covers (canopy, chassis access cover etc.) installed.

Keep ignition switch and isolator in off position.

Do not directly pressure wash the electrical components. Use a low pressure washer and brush to remove dried mud or dirt.

Use a steam cleaner to remove soft dirt and oil.

When cleaning around decals:

- Ensure the water pressure is kept below 138bar (2000psi).
- Keep water temperature below 80C (176F).
- Use a spray nozzle with a 40° wide angle spray pattern.
- Keep the nozzle at least 300mm (12in) away from and perpendicular (at 90° degrees) to the decal.

The machine must always be greased (if appropriate) after pressure washing or steam cleaning.

Storage

General

If the machine will not be used for an extended period, you must store the machine correctly. If you prepare the machine carefully and apply on-going care you can prevent deterioration and damage to the machine while it is in storage.

Storage Area

The machine should be stored in a temperature range of: -40°C (-39.9°F) to 54°C (129.1°F)

When possible, you must keep the machine in a dry building or shelter.

Prepare the Machine for Storage

1. Clean the machine to remove all unwanted material and corrosive products.
2. Dry the machine to remove solvents and moisture.
3. Touch-up any damaged paint.
4. Apply grease to the moving parts (if applicable).
5. Examine the machine for worn or damaged parts. Replace if necessary.
6. Check the hydraulic and hub oil level. Top up if necessary.

Put into Storage

Make sure that the battery is fully charged or at least above 50%.

1. Park the machine on solid, level ground.
 - 1.1. Park the machine in an area where it is easy to access. (In case the machine does not start at the end of the storage period).
 - 1.2. Put suitable timbers under the machine to eliminate direct contact with the ground.
2. Retract all of the rams and fully lower the boom.
3. Vent the hydraulic system.
4. Remove the ignition key.
5. Apply a thin layer of grease or petroleum jelly to all of the exposed ram piston rods.
6. Remove all the batteries.

[Refer to: Battery \(Page 83\).](#)

 - 6.1. Keep all the batteries in warm, dry conditions.
 - 6.2. Charge all the batteries periodically.
7. If you store the machine outside in cold climate and possible snowfall. Cover the platform control with console cover.

During Storage

Operate the machine functions each week to prevent a build up of rust in the machine and hydraulic circuits, and to minimize the deterioration of the hydraulic seals.

Check the charge level of the batteries every 30 days. Charge the batteries if the charge level is below 50%.

[Refer to: Check \(State of Charge\) \(Page 86\).](#)

1. Remove the grease or petroleum jelly from the ram piston rods.

2. Check the hydraulic oil level. If necessary, add more oil.
3. Operate the hydraulic controls. Make sure that the hydraulic functions operate correctly.
4. Prepare the machine for storage.

Take out of Storage

1. Clean the machine to remove all unwanted material and corrosive products. Dry the machine to remove solvents and moisture.
2. Remove the grease or petroleum jelly from the ram piston rods.
3. Check the hydraulic oil level. If necessary, add more oil.
4. Make sure that the batteries are fully charged.
5. Operate the hydraulic controls. Make sure that the hydraulic functions operate correctly.

Maintenance

Introduction

General

Your machine has been designed and built to give maximum performance, economy and ease of use under a wide variety of operating conditions. Prior to delivery, your machine was inspected both at the factory and by your dealer to make sure that it reaches you in optimum condition. To maintain this condition and trouble free operation it is important that the routine services and maintenance, as specified in this manual, are done at the recommended specified intervals and it is recommended that this is done by an approved JCB dealer using genuine JCB parts. Servicing/repairs carried out by unauthorized personnel or the use of non-genuine inferior quality parts could limit machine warranty.

After completing any routine servicing, maintenance or repairs you must complete the functional checks according to the maintenance schedule.

This section of the manual gives full details of the service requirements necessary to maintain your JCB machine at peak efficiency.

Use of electrically insulated tools with PPE's is mandatory to avoid short circuit and electrocution.

It can be seen from the service schedules on the following pages that many essential service checks must only be done by a JCB trained specialist competent person. JCB dealer service engineers have been trained by JCB to do such specialist tasks, and are equipped with the necessary special tools and test equipment to do such tasks, thoroughly, safely, accurately and efficiently.

JCB regularly updates its dealers to advise them of any machine developments, changes in specifications and procedures. Therefore only a JCB dealer is fully able to safely service the machine to the latest requirements, which makes them best placed to maintain and service your machine.

A service record sheet or book is provided at the back of this publication which will enable you to plan your service requirements and keep a service history record. It must be dated, signed and stamped by your dealer each time your machine is serviced.

Remember, if your machine has been correctly maintained, not only will it give you improved reliability but its resale value will be greatly enhanced.

When the machine is removed from service, local regulations for machine decommissioning and disposal will vary. Contact your nearest JCB dealer for further information.

Owner/Operator Support

JCB together with your dealer wants you to be completely satisfied with your new JCB machine. However, if you do have a problem, you can contact your dealer's service department who are there to help you!

You will have been given the names of the relevant service contacts at your dealer when the machine was supplied.

To get the most from your dealer please help them to satisfy you by providing them with:

1. Your name, address and telephone number.
2. Your machine model and serial number.
3. The date of purchase and hours of work.
4. The nature of the problem.

Remember, only your JCB dealer has access to the vast resources available at JCB to help support you. In addition, your dealer is able to offer a variety of programs covering warranty, fixed price servicing, safety inspections, including weight tests, covering both legal and insurance requirements.

It is machine owner's responsibility to ensure that the maintenance is carried out properly in accordance with the requirement of this manual.

Service/Maintenance Agreements

To help plan and spread the costs of maintaining your machine, we strongly recommend you take advantage of the many service and maintenance agreements your dealer can offer. These can be tailor made to meet your operating conditions, work schedule etc.

Please consult your JCB dealer for details.

Obtaining Spare Parts

If you use non-genuine JCB parts or consumables, then you can compromise the health and safety of the operator and cause machine failure.

A parts book for your machine is available from your JCB dealer. The parts book will help you identify parts and order them from your JCB dealer.

Your dealer will need to know the exact model, build and serial number of your machine.

[Refer to: Product and Component Identification \(Page 8\).](#)

Maintenance Safety

General

Raised Machine

Never position yourself or any part of your body under a boom which is not correctly supported. If the machine moves unexpectedly you could become trapped and suffer serious injury or be killed.

Compressed Air

Compressed air is dangerous. Wear personal protective equipment. Never point a compressed air jet at yourself or others.

Springs

Always wear personal protective equipment when dismantling assemblies containing components under pressure from springs. This will protect against eye injury from components accidentally flying out.

Metal Splinters

You can be injured by flying metal splinters when driving metal pins in or out. Use a soft faced hammer or copper drift to remove and install metal pins. Always wear personal protective equipment.

Repairs

If your machine does not function correctly in any way, get it repaired straight away. Neglect of necessary repairs could result in an accident or affect your health. Do not try to do repairs or any other type of maintenance work you do not understand. To avoid injury and/or damage get the work done by a specialist engineer.

Hydraulic Pressure

Hydraulic fluid at system pressure can injure you. Before connecting or removing any hydraulic hose, residual hydraulic pressure trapped in the service hose line must be vented. Make sure the hose service line has been vented before connecting or removing hoses. Make sure the machine cannot be started while the hoses are open.

'O' rings, Seals and Gaskets

Badly installed, damaged or rotted 'O' rings, seals and gaskets can cause leakages and possible accidents. Renew whenever disturbed unless otherwise instructed. Do not use Trichloroethane or paint thinners near 'O' rings and seals.

Soft Ground

A machine can sink into soft ground. Never work under a machine on soft ground.

Working Under the Machine

Make the machine safe. Make sure the park brake is engaged and machine is fully isolated. Remove the machine key switch, disconnect the battery. Use blocks to prevent unintentional movement of the wheels.

Hydraulic Hoses

Never re-use hydraulic hose end crimps or use reusable hose end crimps.

Personal Protective Equipment

Use the appropriate personal protective equipment before performing maintenance on the machine, otherwise you could be injured.

Working at Height

Use appropriate access equipment such as ladders or a working platform if it is necessary to work at height to perform maintenance tasks on the machine. If you do not use suitable access equipment there is a risk of falling, resulting in personal injury or death.

Fluids and Lubricants

Fluid Under Pressure

Fine jets of fluid at high pressure can penetrate the skin. Keep face and hands well clear of fluid under pressure and wear personal protective equipment. Hold a piece of cardboard close to suspected leaks and then examine the cardboard for signs of fluid. If fluid penetrates your skin, get medical help immediately.

Hygiene

JCB lubricants are not a health risk when used correctly for their intended purposes.

However, excessive or prolonged skin contact can remove the natural fats from your skin, causing dryness and irritation.

Low viscosity oils are more likely to do this, so take special care when handling used oils, which might be diluted or contamination.

Whenever you are handling oil products you must maintain good standards of care and personal and plant hygiene. For details of these precautions we advise you to read the relevant publications issued by your local health authority, plus the following.

Storage

Always keep lubricants out of the reach of children.

Never store lubricants in open or unlabeled containers.

Waste Disposal

▲ CAUTION It is illegal to pollute drains, sewers or the ground. Clean up all spilt fluids and/or lubricants.

Used fluids and/or lubricants, filters and contaminated materials must be disposed of in accordance with local regulations. Use authorized waste disposal sites.

CAUTION Damaged or spent batteries and any residue from fires or spillage must be put in a suitable closed receptacle and must be disposed of in accordance with local environmental waste regulations.

All waste products must be disposed of in accordance with all the relevant regulations.

The collection and disposal of used hydraulic oil must be in accordance with any local regulations. Never pour used hydraulic oil into sewers, drains or on the ground.

Handling

New Oil

There are no special precautions needed for the handling or use of new oil, beside the normal care and hygiene practices.

Used Oil

Here are precautions to protect your health when handling used hydraulic oil:

- Avoid prolonged, excessive or repeated skin contact with used oil
- Apply a barrier cream to the skin before handling used oil. Note the following when removing hydraulic oil from skin:
 - Wash your skin thoroughly with soap and water
 - Using a nail brush will help
 - Use special hand cleansers to help clean dirty hands
 - Never use gasoline, diesel, or paraffin for washing
- Avoid skin contact with oil soaked clothing
- Don't keep oily rags in pockets
- Wash dirty clothing before re-use
- Throw away oil-soaked shoes

Battery

Warning Symbols

▲ DANGER Batteries give off an explosive gas. Do not smoke when handling or working on the battery. Keep the battery away from sparks and flames.

Battery electrolyte contains sulfuric acid. It can burn you if it touches your skin or eyes. Wear goggles. Handle the battery carefully to prevent spillage. Keep metallic items (watches, rings, zippers etc) away from the battery terminals. Such items could short the terminals and burn you.

Set all switches to off before disconnecting and connecting the battery. When disconnecting the battery, take off the earth (-) lead first.

Re-charge the battery away from the machine, in a well ventilated area. Switch the charging circuit off before connecting or disconnecting the battery. When you have installed the battery in the machine, wait 5min before connecting it up.

When reconnecting, attach the positive (+) lead first.

Notice: Do not disconnect the battery while the engine is running, otherwise the electrical circuits may be damaged.

CAUTION Understand the electrical circuit before connecting or disconnecting an electrical component. A wrong connection can cause injury and/or damage.


WARNING Battery electrolyte is toxic and corrosive. Do not breathe the gases given off by the battery. Keep the electrolyte away from your clothes, skin, mouth and eyes. Wear safety glasses.

CAUTION Damaged or spent batteries and any residue from fires or spillage must be put in a suitable closed receptacle and must be disposed of in accordance with local environmental waste regulations.

DANGER Batteries give off explosive gases. Keep flames and sparks away from the battery. Do not smoke close to the battery. Make sure there is good ventilation in closed areas where batteries are being used or charged. Do not check the battery charge by shorting the terminals with metal. Use a hydrometer or voltmeter.

The following warning symbols may be found on the battery.

Figure 33.



A Keep away from children

C No smoking, no naked flames, no sparks

E Battery acid

B Shield eyes

D Explosive gas

F Note operating instructions

First Aid - Oil

Eyes

In the case of eye contact, flush with water for 15min. If irritation persists, get medical attention.

Swallowing

If oil is swallowed do not induce vomiting. Get medical advice.

Skin

In the case of excessive skin contact, wash with soap and water.

Spillage

Oil or any flammable liquid should not spill over any heat generating component like batteries, motors, Inverters, charger and cables.

Absorb with sand or a locally approved brand of absorbent granules. Scrape up and remove to a chemical disposal area.

Fires

⚠ **WARNING** Do not use water to put out an oil fire. This will only spread it because oil floats on water.
Extinguish oil and lubricant fires with carbon dioxide, dry chemical or foam.

Maintenance Schedules

General

▲ WARNING Maintenance must be done only by suitably qualified and competent persons.

Before doing any maintenance make sure the machine is safe, it must be correctly parked on solid, level ground.

To prevent anyone starting the machine, remove the key. Disconnect the battery (by means of the battery isolator if installed) when you are not using electrical power. If you do not take these precautions you could be killed or injured.

A badly maintained machine is a danger to the operator and the people working around the operator. Make sure that the regular maintenance and lubrication tasks listed in the service schedules are done to keep the machine in a safe and efficient working condition.

Apart from the daily tasks, the schedules are based on time. Keep a regular check on the hourmeter readings to monitor the hourmeter equivalents. When there is no hourmeter installed, use the calendar equivalents to determine the service intervals.

Do not use a machine which is due for a service. Make sure any defects found during the regular maintenance checks are corrected immediately.

How to Use the Maintenance Schedules

The schedules show the service tasks which must be done and their intervals.

The services must be done at either the hourly interval or the calendar equivalent, whichever occurs first.

The intervals given in the schedules must not be exceeded. If the machine is operated under severe conditions (high temperature, dust, water, etc.) shorten the intervals. Where local regulations require more frequent checks, the local regulations intervals should be followed.

Table 8.

○	Service task can be completed by a competent operator. Details of how to complete the service task are given in the Operator's Manual.
□	We recommend that a Service Engineer completes the service task. Details of how to complete the service task are given in the Service Manual.

Maintenance Intervals

Table 9.

Interval (h)	Calendar Equivalent
6	Daily
20	Weekly
150	Six months
250	Yearly
400	Eighteen months
500	Two years
1250	Five years

Operator Maintenance Tasks

Table 10.

Component	Task	Daily	Weekly	150
Hydraulics				
Hydraulic hoses	Check (condition)	○	○	○
Hydraulic oil	Check (level)	○	○	○

Component	Task	Daily	Weekly	150
Hydraulic oil	Check (leaks)	○	○	○
Electrics				
Battery	Clean	○	○	○
Battery charge	Check	○	○	○
Battery electrolyte level (if applicable)	Check (level)	○	○	○
Battery isolator	Check (operation)	○	○	○
Battery terminal	Clean	○	○	○
Battery leads	Check (condition)	○	○	○
All electrical cables and conductors	Check (condition)	○	○	○
Wiring	Check (condition)		○	○
Equipotential bond cables damage ⁽²⁾	Check (condition)		○	○
RCBO (Residual Current Breaker with Over-Current)	Check (operation)			○
AC (Alternating Current) power to platform cables	Visual inspection			○
AC power to platform cables	Check (operation)			○
Miscellaneous				
Safety labels - renew as required	Check (condition)	○	○	○
Operator's Manual	Check (condition)	○	○	○
Canopy and latches	Check (condition)	○	○	○
Welds	Check (condition)	○	○	○
Fasteners	Check (condition)	○	○	○
Platform guard rail	Check (condition)	○	○	○
Steer pivots	Grease		○	○
Telescopic boom (inner and outer)	Grease (waxoyl)			○
Steering linkages	Check (condition)			○
Limited driving speed (with platform lifted and stowed)	Check (operation)	○	○	○
Tilt sensor	Check (operation)	○	○	○
Limit switch and boom position indicator	Check (operation)	○	○	○
Axle oscillation lock	Check (operation)	○	○	○
Platform leveling	Check (operation)	○	○	○
Travel alarm	Check (operation)	○	○	○
Buzzers	Check (operation)	○	○	○
Platform secondary guarding system	Check (operation)	○	○	○
Slew acknowledgment functions	Check (operation)	○	○	○
Tires and wheels	Check (condition)	○	○	○
Machine damage, missing parts	Check (condition)	○	○	○
Wheel nut	Check (torque)		○	○
Pivot pin nut - rotary actuator	Check (torque)		○	○

Component	Task	Daily	Weekly	150
Slew ring bolts	Check (torque)			○
Counter weight bolts	Check (torque)			○
Base controller				
Emergency stop	Check (operation)	○	○	○
Platform raise and lower functions	Check (operation)	○	○	○
Electric pump	Check (operation)	○	○	○
Ignition switch	Check (operation)	○	○	○
Base control emergency override	Check (operation)	○	○	○
Horn	Check (operation)	○	○	○
Emergency override switch	Check (operation)	○	○	○
Platform controller				
Emergency stop	Check (operation)	○	○	○
Platform raise and lower functions	Check (operation)	○	○	○
Foot pedal switch	Check (operation)	○	○	○
Steering	Check (operation)	○	○	○
Drive and brake	Check (operation)	○	○	○
Worklight (if installed)	Check (operation)	○	○	○
Power to platform (if power tool installed)	Check (operation)	○	○	○
Horn	Check (operation)	○	○	○

(1) Check the charge level of the batteries at least every 30 days. Charge the batteries if the charge level is below 50%.

(2) Check condition and replace if damaged (yellow/green and braided equipotential bond earthing cables).

Service Engineer Maintenance Tasks

Table 11.

Component	Task	250	500
Hydraulics			
Hydraulic hoses	Check (condition)	□	□
Hydraulic oil	Check (level)	□	□
Hydraulic oil	Check (leaks)	□	□
Hydraulic oil	Replace		□
Hydraulic return filter	Replace		□
Suction strainer	Replace		□
Charge pump filter	Replace		□
High pressure filter	Replace		□
Vent filter - hydraulic tank	Replace		□
Electrics			
Battery	Clean	□	□
Battery charge	Check	□	□
Battery electrolyte level (if applicable)	Check (level)	□	□

Component	Task	250	500
Battery isolator	Check (operation)	<input type="checkbox"/>	<input type="checkbox"/>
Battery terminal	Clean	<input type="checkbox"/>	<input type="checkbox"/>
Battery leads	Check (condition)	<input type="checkbox"/>	<input type="checkbox"/>
All electrical cables and conductors	Check (condition)	<input type="checkbox"/>	<input type="checkbox"/>
Wiring	Check (condition)	<input type="checkbox"/>	<input type="checkbox"/>
RCBO (Residual Current Breaker with Over-Current)	Check (operation)	<input type="checkbox"/>	<input type="checkbox"/>
AC (Alternating Current) power to platform cables	Visual inspection	<input type="checkbox"/>	<input type="checkbox"/>
AC power to platform cables	Check (operation)	<input type="checkbox"/>	<input type="checkbox"/>
Equipotential bond cables resistance ⁽²⁾	Check (condition)		<input type="checkbox"/>
Miscellaneous			
Safety labels - renew as required	Check (condition)	<input type="checkbox"/>	<input type="checkbox"/>
Operator's Manual	Check (condition)	<input type="checkbox"/>	<input type="checkbox"/>
Canopy and latches	Check (condition)	<input type="checkbox"/>	<input type="checkbox"/>
Welds	Check (condition)	<input type="checkbox"/>	<input type="checkbox"/>
Fasteners	Check (condition)	<input type="checkbox"/>	<input type="checkbox"/>
Platform guard rail	Check (condition)	<input type="checkbox"/>	<input type="checkbox"/>
Steer pivots	Grease	<input type="checkbox"/>	<input type="checkbox"/>
Hub oil	Check (level)	<input type="checkbox"/>	<input type="checkbox"/>
Hub oil	Replace		<input type="checkbox"/>
Telescopic boom wear pad	Check (condition)		<input type="checkbox"/>
Telescopic boom (inner and outer)	Grease (waxoyl)	<input type="checkbox"/>	<input type="checkbox"/>
Slew bearing	Check (condition)		<input type="checkbox"/>
Limited driving speed (with platform lifted and stowed)	Check (operation)	<input type="checkbox"/>	<input type="checkbox"/>
Tilt sensor	Check (operation)	<input type="checkbox"/>	<input type="checkbox"/>
Limit switch and boom position indicator	Check (operation)	<input type="checkbox"/>	<input type="checkbox"/>
Axle oscillation lock	Check (operation)	<input type="checkbox"/>	<input type="checkbox"/>
Platform leveling	Check (operation)	<input type="checkbox"/>	<input type="checkbox"/>
Overload system	Check (operation)	<input type="checkbox"/>	<input type="checkbox"/>
Hydraulic system pressure	Check (settings)	<input type="checkbox"/>	<input type="checkbox"/>
Hydraulic system functional test	Check (operation)	<input type="checkbox"/>	<input type="checkbox"/>
Overload test	Check (operation)	<input type="checkbox"/>	<input type="checkbox"/>
Drive speed	Check	<input type="checkbox"/>	<input type="checkbox"/>
Boom and slew speed	Check	<input type="checkbox"/>	<input type="checkbox"/>
Steering linkages	Check (condition)	<input type="checkbox"/>	<input type="checkbox"/>
Travel alarm	Check (operation)	<input type="checkbox"/>	<input type="checkbox"/>
Buzzers	Check (operation)	<input type="checkbox"/>	<input type="checkbox"/>
Platform secondary guarding system	Check (operation)	<input type="checkbox"/>	<input type="checkbox"/>
Slew acknowledgment functions	Check (operation)	<input type="checkbox"/>	<input type="checkbox"/>

Component	Task	250	500
Tires and wheels	Check (condition)	<input type="checkbox"/>	<input type="checkbox"/>
Machine damage, missing parts	Check (condition)	<input type="checkbox"/>	<input type="checkbox"/>
Wheel nut	Check (torque)	<input type="checkbox"/>	<input type="checkbox"/>
Pivot pin nut - rotary actuator	Check (torque)	<input type="checkbox"/>	<input type="checkbox"/>
Slew ring bolts	Check (torque)	<input type="checkbox"/>	<input type="checkbox"/>
Counter weight bolts	Check (torque)	<input type="checkbox"/>	<input type="checkbox"/>
Base controller			
Emergency stop	Check (operation)	<input type="checkbox"/>	<input type="checkbox"/>
Platform raise and lower functions	Check (operation)	<input type="checkbox"/>	<input type="checkbox"/>
Electric pump	Check (operation)	<input type="checkbox"/>	<input type="checkbox"/>
Ignition switch	Check (operation)	<input type="checkbox"/>	<input type="checkbox"/>
Base control emergency override	Check (operation)	<input type="checkbox"/>	<input type="checkbox"/>
Horn	Check (operation)	<input type="checkbox"/>	<input type="checkbox"/>
Emergency override switch	Check (operation)	<input type="checkbox"/>	<input type="checkbox"/>
Platform controller			
Emergency stop	Check (operation)	<input type="checkbox"/>	<input type="checkbox"/>
Platform raise and lower functions	Check (operation)	<input type="checkbox"/>	<input type="checkbox"/>
Foot pedal switch	Check (operation)	<input type="checkbox"/>	<input type="checkbox"/>
Steering	Check (operation)	<input type="checkbox"/>	<input type="checkbox"/>
Drive and brake	Check (operation)	<input type="checkbox"/>	<input type="checkbox"/>
Worklight (if installed)	Check (operation)	<input type="checkbox"/>	<input type="checkbox"/>
Power to platform (if power tool installed)	Check (operation)	<input type="checkbox"/>	<input type="checkbox"/>
Horn	Check (operation)	<input type="checkbox"/>	<input type="checkbox"/>

(1) Check the charge level of the batteries at least every 30 days. Charge the batteries if the charge level is below 50%.

(2) Check resistance from ground to the protective earth in the on board charger plug to be no greater than 0.2 ohms.


Maintenance Positions

General

Make the machine safe before you start the maintenance procedure.

1. Park the machine on firm, level ground.
2. Make sure that machine is in stowed position.
3. Turn OFF the machine and remove the key.
4. Turn OFF the battery isolator switch to prevent accidental operation.
5. Put chocks at the front and rear of all wheels.


Figure 34. Platform Lowered Position



Service Points

General

Figure 35.



- A Base control panel
- C Level gage / oil temperature
- E 48V main batteries
- G Hydraulic pump motor

- B Hydraulic tank
- D Battery isolator
- F 12V battery
- H Hydraulic pump

Access Apertures

General

When moved to their maintenance position, the access panels give you access to parts or areas of the machine that are not required during machine operation.

Before you operate the machine, make sure that all of the access panels are correctly in their closed or installed positions.


Battery Cover

Open

Access to the battery compartment is provided by opening the battery cover.

1. Make the machine safe.
2. Release the latches on the both side of the battery cover.
3. Carefully lift the battery cover.
4. Remove the battery cover away from the machine.

Figure 36.



A Battery cover

B Latch

Close


1. Install the battery cover.
2. Make sure the battery cover is correctly latched.

Hydraulic Compartment Cover

To open the cover:

1. Unlock the cover with the ignition key.
2. Push the lock to release the latch.
3. Pull the handle to open the cover.

Figure 37.



A Body panel left side
C Lock

B Handle

To close the cover:


1. Close the cover by pushing the handle firmly; it will latch itself.

Front Cover

To open the chassis front cover:

1. Make the machine safe.
[Refer to: Maintenance Positions \(Page 62\).](#)
2. Get access to the chassis front cover.
3. Remove setscrew (x6) and washers from the cover.

Figure 38.



A Front chassis cover

B Setscrew (x6)

4. Remove the cover plate from the machine.

To close the chassis front cover:


1. Install the chassis front cover.
2. Tighten the setscrew to the specified torque value.
Torque: 22N·m (16.2lb.ft)

Rear Cover

To open the chassis rear cover:

1. Make the machine safe.
[Refer to: Maintenance Positions \(Page 62\).](#)
2. Get access to the chassis rear cover.
3. Remove setscrews (x6) and washers from the cover.

Figure 39.



A Rear chassis cover

B Setscrew (x6)

4. Remove the cover plate from the machine.

To close the chassis rear cover:

1. Install the chassis rear cover.
2. Tighten the setscrews to the specified torque value.

Torque: 22N·m (16.2lb.ft)

Body and Framework

General

Check (Condition)

1. Make sure that all of the guards and protective devices are in position, secured by their locking devices and free from damage.
2. Inspect all of the steelwork for damage. Include the following:
 - 2.1. Examine all of the pivot point welds.
 - 2.2. Examine the condition of all the pivot pins.
 - 2.3. Check that the pivot pins are correctly in position and secured by their locking devices.
3. Check the guardrails are undamaged.
4. Check that all of the safety and instructional labels are undamaged and in position. Install new labels where necessary.
5. Note any damaged paintwork for future repair.
6. Inspect the machine for broken or loose fasteners.

Controls

Check (Operation)

Functional Check

The function checks are designed to discover any malfunctions before the machine is put into service. The operator must follow the step-by-step instructions to test all machine functions. A malfunctioning machine must never be used. If malfunctions are discovered, the machine must be tagged and removed from service. Repairs to the machine may only be made by a qualified service technician, according to the manufacturer's specifications

Pre-Operation Checks

Functional Checks from Base Control

1. Make the machine safe.
2. Select a test area that is firm, level and free of obstruction.
3. Insert key and turn to ON position.
 - 3.1. The display switches ON and buzzers at base and platform beeps 3 times.
4. No alarm information should be displayed on screen.

Horn Button Check

1. Press the horn button from base and platform control panel, the horn should sound.

Emergency Stop Button Check

1. Insert key and turn to ON position.
2. Press the "emergency stop" button at the base.
 - 2.1. The machine should not function.
 - 2.2. Release the "emergency stop" button at the base, and make sure machine functions normally.
3. Press the platform "emergency stop" button and release the base "emergency stop" button.
 - 3.1. The machine should not function.
 - 3.2. Release the platform "emergency stop" button, and make sure machine functions normally.

Base Control Function Test

Enable Switch Check

1. Release the "Enable / Auxiliary Power Switch" and push the functions button. The functions of the machine will be deactivated.
2. Press and hold the "Enable / Auxiliary Power Switch", and push the function buttons. The machine will function normally.

Check following boom function with base enable pressed down. For machine stowed and raised position, [Refer to: Instrument Panel \(Page 22\)](#).

Main Boom Function Check

1. Push up the main boom toggle switch. The main boom raises steadily. Make sure there is no jitter or abnormal sound.
2. Push down the main boom toggle switch. The main boom lowers steadily. Make sure there is no jitter or abnormal sound.

Articulated Boom Function Check

1. Push up the articulated boom toggle switch. The articulated boom is raises steadily. Make sure there is no jitter or abnormal sound.
2. Push down the articulated boom toggle switch. The articulated boom lowers steadily. Make sure there is no jitter or abnormal sound.

Telescopic Boom Extend/Retract Check

1. Push the telescopic boom toggle switch to right. The telescopic boom extends steadily. Make sure there is no jitter or abnormal sound.
2. Push the telescopic boom toggle switch to left. The telescopic boom retracts steadily. Make sure there is no jitter or abnormal sound.

Platform Level Function Check

1. Push up platform level toggle switch. The basket and jib moves upward.
2. Push down platform level toggle switch. The basket and jib moves downward.

Platform Rotary Actuator Check

1. Press platform rotate toggle switch to left, the platform rotates clockwise direction (from plan view).
2. Press platform rotate toggle switch to right, the platform rotates counter clockwise direction (from plan view).

Slew Rotation Check

Make sure the slew lock pin is not engaged with turntable and then start test as follows:

1. Push the slew toggle switch to the left, the turntable swings clockwise (from plan view), and the buzzer sounds.
2. Push the slew toggle switch to the right, the turntable swings counter clockwise (from plan view), and the buzzer sounds.

Jib Function Check

1. Push the jib toggle switch up, the jib moves upward.
2. Push the jib toggle switch down, the jib moves down.

Auxiliary Power Function Check

1. Make sure that the ignition key is in the ON position.
 - 1.1. When the base control enable switch is operated and the pump motor gives DTC error, base 'AUX' mode will be activated and boom function will operate normally.
 - 1.2. To conserve battery power, test each function through a partial cycle.

Emergency Override Check

1. Navigate to base inputs in the display menu.
2. Press the emergency override switch.
3. Check that the display shows the emergency override switch input is activated.
4. The base override switch must be pressed during start-up (an ignition cycle with the override button pressed is required) to activate the base override mode.
5. The base override switch must be held down to remain in base override mode.
6. Platform emergency stop and / or overload do not have to be active conditions to activate the override mode.

7. When the override mode is activated, the message base override appears on the display of the base.
8. When the override mode is activated, a beep sounds.
9. When base override mode is activated, only base controls are active. Platform controls are ignored.
10. When the base override mode is activated, the movements are only driven by the auxiliary pump (electric).
11. The auxiliary pump (electric) is only activated when a boom function switch for the linkage is pressed in addition to the base override switch. The selector switch for the base / platform is ignored.
12. When the base override mode is activated, the functions of the boom are activated one after the other. There is no multifunctionality.
13. There will be NO drive controls with the override function.
14. The base override mode ignores the following safety functions:
 - 14.1. Platform emergency stop and platform emergency stop fault reactions
 - 14.2. Overload conditions and load sensor fault reactions
15. It does not override the safe state responses of any other safety functions.
16. The base override mode enables function that are disabled by:
 - 16.1. CAN-disconnected faults at platform ECU (Electronic Control Unit) (base ECU outputs only)
 - 16.2. VIN check failure
 - 16.3. Limit switch faults (enable raise and extend functions, but continue to default to raised state condition)
 - 16.4. Output faults for base and platform ECUs (including safout faults)
17. The base override mode shall not ignore the base emergency stop.
18. When the basic override mode has been activated, the icon "historical override activated" is displayed. This is only cleared by a message from servicemaster / display to the base ECU.

Platform Control Function Check

General Check from Platform

1. Insert key and turn to ON position.
 - 1.1. The display switches ON and buzzer at base and platform beeps 3 times.
2. No alarm information should be displayed on screen. Tilt indicator / overweight indicator / user caution / fault indicator should be in OFF condition.

Foot Switch Check

1. Release the foot switch, push control levers, the machine functions are not active.
2. Press the foot switch, push control levers, the machine operates correctly.
3. Push a function lever, and then press the foot switch, this machine function is not active.
4. Press the foot switch for 10 seconds and then push each function lever, the machine functions are not active.

Travel/Steer Check

1. Push the travel/steer joystick forward, the machine moves forward. Make sure there is no jerk and the machine is running smoothly. Release the joystick and the machine stops moving.
2. Push the travel joystick backward, the machine moves backward. Make sure there is no jerk and the machine is running smoothly. Release the joystick and the machine stops moving.

3. Check individual limit switches for working height; tele-boom extended, tele-boom raised and articulated boom raised up 10 feet/ 3 m travel speed should be reduced.
4. Press the steer left button on the top of the travel joystick, the wheels should turn to the left whilst the button is pressed.
5. Press the steer right button on the top of the travel joystick, the wheels should turn to the right whilst the button is pressed.

Main Boom Check

1. Push forward main boom/slew joystick, main boom is raises steadily. Make sure there is no jitter or abnormal sound.
 - 1.1. The rising speed varies depending on the change in joystick movement amplitude. When the joystick movement is small, the speed is low.
2. Push down the main boom toggle switch, main boom is lowers steadily. Make sure there is no jitter or abnormal sound.
 - 2.1. The lowering speed varies depending on the change in joystick movement amplitude. When the joystick movement is small, the speed is low and the travel alarm sounds.

Machine Slew Check

Make sure the slew lock pin is not engaged with turntable and then start test as follows:

1. Push the turntable slew joystick to the left, the turntable slews clockwise (from plan view).
 - 1.1. The slew speed varies depending on the joystick movement amplitude.
 - 1.2. When the telescopic boom is extended, slew is smooth and there is no jerk sound.
 - 1.3. When the joystick movement is small, the speed is low. The travel alarm sounds.
2. Push the turntable slew joystick to the right, the turntable slews counter clockwise (from plan view).
 - 2.1. The slew speed varies depending on the joystick movement amplitude.
 - 2.2. When the telescopic boom is extended, slew is smooth and there is no jerk or abnormal sound.
 - 2.3. When the joystick movement is small, the speed is low. The travel alarm sounds.

Articulated Boom Check

1. Push up the articulated boom toggle switch, the articulated boom raises smoothly. Make sure there is no jitter or abnormal sound.
 - 1.1. There is no jerk when it is raising to the full extent.
2. Push down the articulated boom toggle switch, the articulated boom lowers smoothly. Make sure there is no jitter or abnormal sound.
 - 2.1. There is no jerk when it is lowering to the full extent. The travel alarm sounds.

Telescopic Boom Extend/Retract Check

1. Push down the telescopic boom toggle switch, the telescopic boom is extending smoothly. Make sure there is no jitter or abnormal sound.
2. Push up the telescopic boom toggle switch, the telescopic boom is retracting smoothly. Make sure there is no jitter and abnormal sound.
 - 2.1. There is no jerk when it is retracting to the full extent. The travel alarm sounds.

Platform Level Check

1. Push up platform level toggle switch, the basket and jib rotates upward.

2. Push down platform level toggle switch, the basket and jib rotates downward.

Automatic Leveling Check

1. When the main boom is lifting and lowering, leveling happens without jitter or delay.

Platform Rotary Actuator Check

1. Push platform rotate toggle switch to left, the platform rotates clockwise direction (from plan view).
2. Push platform rotate toggle switch to right, the platform rotates counter clockwise direction (from plan view).

Jib Function Check

1. Push the jib toggle switch up, the jib moves upward.
2. Push the jib toggle switch down, the jib moves down.

Speed Control Function Check

The speed control switch affects the speeds of all functions operated by toggle switches and the travel speed, when operating from the platform control panel only. The readings of the speed control switch are proportional to the speed of the function.

It is possible that with the potentiometer in the minimum position some services may not move when operated from platform control panel. Adjustment of the potentiometer will ensure smooth movement.

Auxiliary Function Check

1. Make sure that the ignition key is in the ON position.
2. Press and hold the "Auxiliary power button" while pushing the boom function button, the boom functions normally.
 - 2.1. To conserve battery power, test each function through a partial cycle.

Slew Acknowledgment Travel Interlock Check

Make sure the slew lock pin is not engaged with turntable and then start test as follows:

1. Slew the turntable outside in forward position. The slew acknowledgment LED (Light Emitting Diode) will start flashing and the travel function will be de-active.
2. Press the slew acknowledgment button, the LED turns solid and the travel function is enabled.
3. Release the foot switch and check the platform slew acknowledge LED is flashing.
4. Slew inside forward position, check the platform slew acknowledge LED is OFF.

Drive and Brake Check

[Refer to: Check \(Operation\) \(Page 78\).](#)

Safety Equipment

Check (Operation)

Safety Function Check

If any of the safety equipment is defective stop using the machine until the defect has been rectified.

Emergency Stop Check

Proper functioning of emergency stop buttons are essential for safe machine operation. An improperly operating emergency stop button will fail to shut off power and stop all machine functions, resulting in a hazardous situation for ground and platform personnel.

1. Turn key to ON position.
2. Push the emergency stop button to OFF position. The display should show that the emergency stop has been pressed, and no machine function should operate.

The platform emergency stop button will stop all machine operation, even if base control is selected. Also, the base control emergency stop button will stop all machine operation, even if the platform control is selected.

The platform emergency stop can be overridden by the ground override control.

[Refer to: Moving a Disabled Machine \(Page 38\).](#)

Tilt Sensor Check

If the machine drives on a slope and the chassis exceeds the maximum rated angle at 5°, an alarm will sound. Travel and boom raise functions will be disabled until the boom is lowered to its stowed position.

[Refer to: General \(Page 32\).](#) The chassis angle is detected by the tilt sensor.

1. Park the machine on firm level ground.
2. Raise/extend the main boom.
3. Push the tilt sensor down on one side until the sensor is tilted at its highest angle. Hold the tilt sensor down at least for the specified duration.
Duration: 1.5s
4. Check that the alarm should sound at the platform and base control, the tilt alarm icon should flash on the platform control and the base control panel

Axle Oscillation

The machine is installed with an oscillating front axle. The machine stability will be affected if the axle locking system is damaged.

1. Make the machine safe.
2. Turn the machine ON.
3. Drive the right front wheel on the barrier at the specified height. The front axle should be free to tilt.
Distance: 150mm (6in)
4. Make sure that the other three wheels are on the ground and are at a level position.
5. Extend the telescopic boom to the specified distance.
Distance: 500mm (19½in)
6. Drive the right front wheel off the barrier. The front axle should be locked.
7. Make sure that the front right wheel remains off the ground.

Main Boom Down Limit Switch

The boom down limit switch is an important safety device that indicates if the machine is at boom raised position or stowed position. Before you check the boom down limit switch operation, make sure that the machine boom is at its stowed position.

1. Raise the main boom from base control or platform control to the specified height.
Distance: 1,130 ± 100mm (44½ ± 4in)
2. Check the base control display icon changes from the stowed to boom raised position.
3. Lower the main boom and check display icon changes to the stowed position.

Articulated Boom Down Limit Switch

Articulated boom down limit switch is an important safety equipment that indicates if the machine is at boom raised position or stowed position. Before you check the articulated boom down limit switch operation, make sure that the machine boom is at stowed position.

1. Raise the articulated boom from base control or platform control to specified height.
Distance: 940 ± 100mm (37 ± 4in)
2. Check the base control display icon changes from stowed to boom raised position.
3. Lower the articulated boom and check display icon changed to stowed position.
4. If the display does not change then do not drive the machine with boom raised.

Tele-detect Limit Switch Check

This switch detects the extension and retraction of tele-boom.

1. Make sure that the machine is at its stowed position.
2. Extend the tele-boom from the base control or platform control to the specified distance.
Distance: 200mm (8in)
3. Check the display changes from the stowed to the elevated position.
4. Retract the boom and check the display changes to the stowed position.
5. Make a note that the machine will be in stowed position between the specified stroke.
Distance: 0–180mm (0–7in)

Machine Drive Speed Check

The machine maximum speed is limited by software with boom raised position.

1. From the platform control, perform boom operation (articulated/ main boom raise or teleboom extend) so the machine shows raised position.
2. Drive the machine to specified distance and record the speed.
Distance: 10m (11yd)
3. The machine should cover this speed in not less than the specified duration.
Duration: 40s

Table 12.

Raise or elevated, maximum moving speed	0.9km/h (0.6mph)
---	------------------

Platform Secondary Guarding System Check

1. From platform control, raise the platform by main boom or articulated boom to the boom raised position.
2. Press the secondary guarding system cable and check platform warning LED (Light Emitting Diode) flashes and buzzer sounds.
3. Check all drive, raise and extend functions are disabled from the base and the platform control.
4. Check all other functions are enabled.
5. Release the secondary guarding system reset switch and check fault indicators are cleared.
6. Check all functions are enabled from the base and the platform.

Weight Sensor Check

1. The platform is calibrated for 300 kg payload.
2. With empty platform condition the load cell reading on the display should show 0 kg and 0%.
3. With around 80 kg (1 operator) it show 80 kg and 27% and with around 240 kg load it should show 240 kg and 80%.
4. With 300 kg in the platform it shows 100% load.
5. With 305 kg platform overload the icon turns on with a buzzer sound and all functions from the base and platform control panel will be disabled.
6. To reset the load sensing, enough weight must be removed to go below 95% load due to hysteresis.
7. Check all the functions are enabled from the base and platform control.

Slew Acknowledge for Enabling Drive


The machine is equipped with a safety feature to detect the machine is in the forward drive position or outside forward drive position.

If the booms are slewed more than the specified angle from the forward position (between the non-steer wheels), drive and steer functions will not be available until the operator acknowledges the slew orientation. Angle: +/- 55 degree.

1. Slew the machine inward, so that it is in the forward drive position and check slew acknowledgment LED is OFF.
2. Make sure that drive is enabled. Drive the machine in forward or reverse
3. Slew the machine outside the forward drive position. Check the slew acknowledgment LED is flashing.
4. Check that drive is disabled.
5. Press the foot pedal and press the slew acknowledgment reset button. Check the slew acknowledgment LED turns on.
6. Check that drive is enabled when the foot pedal remains pressed.
7. Release the foot pedal and check that the LED is flashing and drive is disabled without the slew acknowledgment reset button being pressed.

The main boom, articulated boom and telescopic boom switch position limits are shown below [Refer to Figure 40](#). The combined effect of these limit switch positions is a change in platform height of 1.5m from the fully stowed position. With the jib fully raised, the platform height can be up to 4.9m at the limits of these switch positions.

Figure 40.



A 4.9m (5½yd)

Brakes

General

Check (Operation)

The brakes must be able to hold the machine on any slope it is able to climb up to the permissible value.
[Refer to: Driving on Slopes \(Page 28\).](#)

Make a note of the following.

- You must check the brakes for correct operation at regular intervals.
[Refer to: Maintenance Schedules \(Page 57\).](#)
 - The correct brake function is necessary for safe machine operation.
 - The brake function must operate smoothly, free of hesitation, jerking and unusual noise.
 - Carry out this procedure with the machine on a firm, level surface that is free of obstructions.
1. Make the machine safe with the platform lowered.
 2. Put a mark on the ground to use as a test line.
 3. Turn the ignition switch to platform control.
 4. Release the base emergency stop button to the ON position.
 5. Release the platform emergency stop button to the ON position.
 6. Make a note of the point on the machine (contact patch of a tire) as a visual reference when you cross the test line.
 7. Press the drive function button (if installed).
 8. Press and hold the drive / steer function enable switch on the control handle.
 9. Move the control lever in the forward direction.
 10. Bring the machine to top drive speed before you reach the test line.
 11. Release the control lever when the selected reference point on the machine crosses the test line.
 12. Measure the distance between the test line and the machine reference point.
 13. Make sure that the braking distance is within the specified limits.
 14. Raise the platform.
 15. Do the steps 2 to 12 with the platform raised.
 16. Make sure that the braking distance is within the specified limits.

[Refer to: General \(Page 99\).](#)

Steering System

General

Check (Operation)

1. Enable the joystick by pressing the foot pedal switch at platform.
[Refer to: Main Component Locations \(Page 7\).](#)
2. Press the joystick (forward/back).
3. Press the left steering switch to turn left.
4. Press the right steering switch to turn right.

Tires

General

Check (Condition)

Always drive with consideration for the condition of the tires. Check the tires daily for the signs of damage and wear. For example:

- Signs of distortion
- Cuts
- Embedded objects (nails, etc.)
- Continuous tread
- Edge damage
- Uneven wear
- Compare wear between tires

Never modify tires or install tires which are not intended for use on this machine. Contact you local JCB dealer to replace the parts.

Changing specification of tires may require a change of counterweight, check with your JCB dealer.

Hydraulic System

Oil

Check (Level)

1. Make the machine safe with the boom lowered.
2. Get access to the hydraulic oil level indicator and hydraulic oil filler cap.
[Refer to: Service Points \(Page 63\).](#)
3. Check the hydraulic oil level indicator. The hydraulic oil level must be visible in the level indicator.
4. Make sure that the hydraulic oil does not exceed specified temperature on the hydraulic tank gage.
Temperature: 80°C (175.9°F)
5. Top up oil level if necessary:
 - 5.1. Remove the hydraulic oil filler cap.
 - 5.2. Add hydraulic oil.
[Refer to: Fluids, Lubricants and Capacities \(Page 104\).](#)
 - 5.3. Install the filler cap.

Electrical System

General

Check (Operation)

Make sure all of the electrical equipment operates correctly, for example:

- Switches
- Warning lights
- Beacon
- Alarms
- Horn
- Hourmeter/display
- Battery
- Lights

All defective equipment must be repaired before the machine is used.

Limit Switches and Boom Position Indicator

1. There must be two main states of the machine.
 - 1.1. Stowed Mode
 - 1.2. Raised Mode
2. The machine state must be identified by, telescope retract limit switch, articulated lower limit switch and main boom lower limit switch (Raised mode must be 'OR' Condition).
3. If all of these switches indicate that all of these booms are in the stowed position, the Base ECU (Electronic Control Unit) must log that the machine is in the "stowed mode" (Stowed mode must be 'AND' condition).
4. There is an icon at base display to show the correct operating state of machine to the operator. Refer Base Control display in
[Refer to: Instrument Panel \(Page 22\).](#)
5. Under any of these limit switch's fault condition, the default working state is set to Raised Mode.

Check (Condition)

▲ WARNING Battery electrolyte is toxic and corrosive. Do not breathe the gases given off by the battery. Keep the electrolyte away from your clothes, skin, mouth and eyes. Wear safety glasses.

DANGER Batteries give off explosive gases. Keep flames and sparks away from the battery. Do not smoke close to the battery. Make sure there is good ventilation in closed areas where batteries are being used or charged. Do not check the battery charge by shorting the terminals with metal. Use a hydrometer or voltmeter.

CAUTION Understand the electrical circuit before connecting or disconnecting an electrical component. A wrong connection can cause injury and/or damage.

Examine the electrical circuits regularly for:

- Damaged connectors
- Loose connections
- Chafing on the wiring harnesses
- Corrosion
- Missing insulation
- Incorrect routeing of the wiring harnesses
- Insulation covers on battery terminals and leads

Do not use the machine if one or more of these faults are found. You must make sure that the electrical circuit is repaired immediately.


Battery

Clean

⚠ WARNING Keep metal watch straps and any metal fasteners on your clothes, clear of the positive (+) battery terminal. Such items can short between the terminal and nearby metal work. If it happens you can get burned.

1. Make the machine safe.
[Refer to: Maintenance Positions \(Page 62\).](#)
2. Get access to the battery.
[Refer to: Access Apertures \(Page 64\).](#)
3. If the terminal posts are corroded and covered with white powder wash them with hot water. If there is considerable corrosion, clean the terminal posts with a wire brush or abrasive paper. [Refer to Figure 41.](#)

Figure 41.



4. Apply a thin layer of petroleum jelly to the terminal posts.

Connect

⚠ WARNING Keep metal watch straps and any metal fasteners on your clothes, clear of the positive (+) battery terminal. Such items can short between the terminal and nearby metal work. If it happens you can get burned.

CAUTION The machine is negatively earthed. Always connect the negative pole of the battery to earth.

When connecting the battery, connect the earth (-) lead last.


When disconnecting the battery, disconnect the earth (-) lead first.

CAUTION Understand the electrical circuit before connecting or disconnecting an electrical component. A wrong connection can cause injury and/or damage.

12V Battery

1. Make the machine safe.
[Refer to: Maintenance Positions \(Page 62\).](#)
2. Open the hydraulic compartment cover to access the battery.
[Refer to: Access Apertures \(Page 64\).](#)
3. Connect the battery cables.

Figure 42.



A Negative terminal clamp


B Positive terminal clamp

- 3.1. Connect the positive terminal first then the negative terminal.
- 3.2. Battery terminal should make full contact with cable clamp.
- 3.3. Connect cable clamps to respective positive and negative battery terminal according to mark on cable clamp. (Positive and Negative battery terminal sizes are different for error proofing.)
4. Use the battery isolator to connect the battery.

48V Batteries

1. Make the machine safe.
[Refer to: Maintenance Positions \(Page 62\).](#)
2. Open the battery cover to access the batteries.
[Refer to: Access Apertures \(Page 64\).](#)
3. Connect the battery link leads and battery cables. [Refer to Figure 43.](#)
 - 3.1. Connect the battery positive terminal first then the negative terminal. [Refer to Figure 43.](#)
4. Use the battery isolator to connect the battery.

Figure 43.



A Left side batteries
C Battery cable
E Positive terminal

B Right side batteries
D Negative terminal
F Battery link leads

Disconnect

⚠ WARNING Keep metal watch straps and any metal fasteners on your clothes, clear of the positive (+) battery terminal. Such items can short between the terminal and nearby metal work. If it happens you can get burned.

CAUTION The machine is negatively earthed. Always connect the negative pole of the battery to earth.

When connecting the battery, connect the earth (-) lead last.

When disconnecting the battery, disconnect the earth (-) lead first.

CAUTION Understand the electrical circuit before connecting or disconnecting an electrical component. A wrong connection can cause injury and/or damage.

12V Battery

1. Make the machine safe.
[Refer to: Maintenance Positions \(Page 62\).](#)
2. Turn the battery isolator switch to the OFF position.
[Refer to: Service Disconnect \(Page 18\).](#)
3. Open the hydraulic compartment cover to access the battery.
[Refer to: Access Apertures \(Page 64\).](#)
4. Disconnect the battery cables.
 - 4.1. Disconnect the battery negative terminal first then the positive terminal.

48V Batteries

1. Make the machine safe.

[Refer to: Maintenance Positions \(Page 62\).](#)

2. Turn the battery isolator switch to the OFF position.

[Refer to: Service Disconnect \(Page 18\).](#)


3. Open the battery cover to access the batteries.

[Refer to: Access Apertures \(Page 64\).](#)

4. Disconnect and remove the battery link leads and battery cables.

4.1. Disconnect the battery negative terminal first then the positive terminal. [Refer to Figure 44.](#)

Figure 44.



A Left side batteries
C Battery cable
E Positive terminal

B Right side batteries
D Negative terminal
F Battery link leads

Check (State of Charge)

General Check (Before Charging)

- The battery charge level is displayed on the instrument panel. (while the machine is not charging). [Refer to: Instruments \(Page 22\).](#)
- Reset the ignition key to check the battery charge level.
- Charge the battery fully after each use.
- Do not charge, when the ambient temperature is above 46°C (114.7°F).
- Do not use an external charger.
- The battery is only suitable for this particular product. Never use this battery with other equipment.
- Do not short-circuit the battery output.
- Do not immerse the battery in water, acid, alkaline or a salt solution.

Charging

1. Park the machine in an appropriate charging area.

1.1. Make sure that the charging area is covered and duly ventilated.

2. Switch OFF the ignition, remove the key and isolate the machine.
3. Remove the battery cover.
4. Connect the power supply to the charging cable connector.
5. Switch ON the power supply.
6. Wait until charging has completed.
Duration: 8h
7. To check battery charge level disconnect battery charge cable and reset ignition key.

Service Disconnect

Check (Operation)

▲ Notice: Do not isolate the machine electrics when the machine is in operation, this may cause damage to the machine electrics.

1. Isolate the machine electrics.
[Refer to: Service Disconnect \(Page 18\).](#)
2. Make sure that the machine electrics are isolated.

A defective isolator must be repaired before the machine is used. For more information, contact your JCB dealer.

Fuses

Replace

The electrical circuits are protected by fuses. If a fuse blows, find out why before a new one is installed.

Notice: Always replace fuses with ones of correct ampere rating to avoid electrical system damage.

Notice: Fuses and relays in the hazardous voltage system must not be replaced, consult your JCB dealer.


For more information on the individual fuses.

[Refer to: Fuses \(Page 106\).](#)

Busbar and harness Fuses

The busbar and harness fuses are situated inside the rear chassis cover. Remove the rear chassis cover to get access to the fuses.

Figure 45.




A Busbar fuses
C Screws

B Rear chassis cover
D Harness fuses

Base Control Panel Fuses

Open the base control panel to get access to the fuses.

Figure 46.




A Base control fuses

Platform Control Fuse

Open the platform control panel to get access to the platform control fuse.

Figure 47.



A Platform control fuse

B Platform control relay

Relays

Replace


For more information on the individual relays.

[Refer to: Relays \(Page 108\).](#)

Base Control Relays

Open the base control panel to get access to the base control relays.

Figure 48.




A Relays

Platform Control Relay

Open the platform control panel to get access to the platform control relay.

Figure 49.



A Platform control fuse

B Platform control relay



Notes:

Technical Data

Introduction

General

All the rated operating capacities/rated lift capacities are based on the criteria of the machine being level on a firm supporting ground and wind speed is below the specified limit.

Static Dimensions

Dimensions

Figure 50.




Figure 51.




Table 13.

Items	Description	Length
A	Height-stowed	2.23m (7ft 3.8in)
B	Length-stowed	7.04m (23ft 1.2in)
C	Platform height	1.2m (3ft 11in)
D	Ground clearance	0.32m (1ft 0.6in)
E	Wheelbase	2.03m (6ft 7in)
F	Width	2.26m (7ft 4in)
G	Platform - width	1.9m (6ft 3in)
H	Platform - length	0.85m (2ft 9in)

Items	Description	Length
J	Maximum working height	15.5m (50ft 10in)
K	Maximum platform height ⁽²⁾	13.8m (45ft 3in)
L	Maximum horizontal reach	8.05m (26ft 5in)
M	Up and over clearance ⁽¹⁾	7.5m (24ft 7in)

(1) The maximum height that the basket can reach when the main telescopic boom is angled horizontally.

(2) Maximum working height adds 2m to the metric platform height, and adds 6ft to the imperial platform height, based on regional norms.

Weights

Table 14.

Description	Weight
Overall weight (approximate)	7,900kg (17,416.34lb)
Load capacity	300kg (661.38lb)
Platform entry type	Drop bar
Platform entry number	3
Platform occupancy	2 persons
Maximum manual force	400N (89.92lb)
Maximum ground wheel load	4,230kg (9,325.46lb)
Maximum localized ground pressure per tire	5,798 kN/m ²

Visibility Diagrams

The visibility maps provided in this manual are for guidance, and may be used to improve visibility or as part of a risk assessment for work site safe operation, introduction of additional visual aids or site management.


The visibility map(s) show machines in standard configuration. Modifications or environment may increase or add blind spots around the machine. It is the responsibility of the operator and worksite management to determine if the visibility for the machine in its worksite is acceptable.

The visibility map(s) shows the combined approximate blind spots of direct vision. The operator's eye position is 1.62m above the platform floor, 0.4m in from the side and 0.5m in from the front of the platform. This represents what a standing operator can approximately see from the front-right default controller position.

Dimension for Setup

The evaluation has been completed from the eye point of the operators as they stand on the access platform at the control box.


Figure 52.



Average Height Operator

The gray areas shown in the image on the left and the shaded areas around the machine in the image on the right highlight the areas that cannot be seen by the operator when they are stood on the access platform.

Figure 53.



Distance from the front of the machine to the most forward edge that cannot be seen behind the counterweight (shown by the arrows) = 4.274m (14ft).

Performance Dimensions

General

Table 15. Drive Speed Checks

Description	Data
Maximum stowed drive speed	7km/h (4.3mph)
Maximum elevated drive speed (kph)	0.9km/h (0.6mph)
Maximum wind speed	12.5m/s (41.0feet/s)
Maximum inclination (front/ side/ rear)	5°
Maximum gradability	40%
Turning radius (outside)	4.7m (5yd)
Turning radius (inside)	2.7m (3yd)
Drive and steer	4WD, 2WS
Brake	4

Table 16. Check Cycle Time

Parameters		Motor RPM		Cycle time in Seconds	
		Base	Platform	Base	Platform
Articulated boom	Raise	1500	1730	29±3	26±3
	Lower	1500	1500	40±3	40±3
Main boom	Raise	1500	1730	27±3	24±3
	Lower	1500	1270	21±3	21±3
Telescopic boom horizontal	Extend	1500	1900	18±2	13±2
	Retract	1500	1975	11±2	11±2
Telescopic boom vertical	Extend	1500	1900	18±2	13±2
	Retract	1500	1950	11±2	11±2
Jib boom	Raise	1500	650	23±3	23±3
	Lower	1500	500	17±3	17±3
Rotary joint	Left	1500	500	20±5	20±5
	Right	1500	500	20±5	20±5
Slew 90 deg from forward position	Stow - slew left	1500	920	20±4	20±4
	Stow - slew right	1500	920	20±4	20±4
	Raised - slew left	1500	920	32±6	32±6
	Raised - slew right	1500	920	32±6	32±6
Leveling	Leveling up	1500		58±12	58±12
	Leveling down	1500		45±12	45±12
Steer	Left		2500	NA	3±1
Steer right	Right		2500	NA	3±1
Machine fully raised and lower as earliest as possible	Raise			100±15	86±15
	Lower			100±15	86±15
<ul style="list-style-type: none"> Raise: Articulated boom + Main boom -> Telescopic boom -> Jib boom in last Lower: Telescopic boom -> Articulated boom + Main boom -> Jib boom 					


Parameters		Motor RPM		Cycle time in Seconds	
		Base	Platform	Base	Platform
Machine fully raised and lower as earliest as possible	Raise			80±15	80±15
	Lower			80±15	80±15
<ul style="list-style-type: none"> • Raise: Main boom + Jib boom -> Articulated boom -> Telescopic boom in last • Lower: Telescopic boom -> Articulated boom -> Main boom + Jib boom 					

Table 17. Braking Distance

Test conditions	Braking distance
Stowed condition, low torque, hare mode on flat ground	2m (2yd)
Stowed condition, low torque, tortoise mode on flat ground	1m (1yd)
Elevated mode, low torque, hare mode on flat ground	0.1m (0yd)

Boom Dimensions and Performance

Figure 54.



Noise Emissions

Noise Data

All Machines

Noise value does not exceed 75dB.

Vibration Emissions

Vibration Data

Whole-body vibration emission in accordance with ISO 2631-1:1997 does not exceed 0.5m/s.

Hand-arm vibration determined in accordance with dynamic test conditions defined in ISO 5349-2:2001 does not exceed 2.5m/s.

Fluids, Lubricants and Capacities

General

JCB recommend that you use the JCB lubricants shown as they have been verified by JCB for use on JCB machines. However, you could use other lubricants that are equivalent to the JCB standards and quality or offer the same machine component protection.

Table 18. Fluids, Lubricants and Capacities

Item	Capacity L (UKgal)	Fluid/Lubricant	JCB Part Number	Container Size ⁽¹⁾	Specification
Hydraulic System	System 75L (16½UKgal) and Tank 55L (12¾UKgal)	-12°C (10.4°F) to 46°C (114.7°F): JCB Hydraulic Fluid HP32	4002/1000	20L (4¼UK-gal)	VG32 Grade oil
		Max 51°C (123.7°F): JCB Hydraulic Fluid OP46	4002/3000		HV46 Grade oil: Hot climate region
Slew Ring Bearings	As required	JCB HP Grease	4003/2017	0.4kg (0.88lb)	
Slew Ring Gear Teeth	As required	JCB Special Slew Pinion Grease	4003/1619	0.4 (0.88)	
Hub Oil	0.68L (½UK-gal)	JCB Ultra Performance Gear Oil 150	4000/4901 (India)	5L (1¾UK-gal)	
		Gear oil 80W90	4000/3400 (UK)		MIL-PRF-2105E
All Other Grease	As required	JCB MPL-EP Grease	4003/1501	0.4 (0.88)	
		JCB HP Grease (optional)	4003/2017		

(1) For information about the different container sizes that are available (and their part numbers), contact your local JCB dealer.

Torque Values

General

Table 19.

Item	Torque
	N·m (lb.ft)
Wheel nut	210 (154.9)
Pivot pin nut - rotary actuator	823 (607.0)
Slew ring bolts	259 (191.0)
Counter weight bolts	621 (458.0)

Electrical System

General

Table 20. 12V Battery

Item	Specification
Battery voltage	12V
Capacity	110Ah
CCA (Cold Cranking Amps)	900

Table 21. 48V Batteries

Battery capacity	400Ah
Battery Type	Lead acid
Battery Voltage	48V
Battery pack nominal voltage	48V
Battery Life (80% DOD (Depth of Discharge))	800 cycles
Operating temperature range	-20–60°C (-4.0–139.9°F)
8 batteries series connected output	48V

Table 22. Charger Specification

Item	Specification
IP Rating	65
Input	100–240V 13A 50–60Hz
Output	48V DC, 68A max

Table 23. Front Drive Motor

Item	Specification
Motor Type	3 phase AC motor IPM
IP Rating	67
Power	6kW (8.0hp)
Voltage	32V AC (Alternating Current)

Table 24. Rear Drive 2 motors

Item	Specification
Motor Type	3 phase AC induction motor
IP Rating	54
Power	3.15kW (4.2hp)
Voltage	32V AC

Table 25. Pump Motor 3 Phase - Hydraulic Drive

Item	Specification
Type	3 phase AC motor IPM
IP Rating	54
Power	9.1kW (12.2hp)
Voltage	32V AC

Fuses


Primary Fuses

Table 26.

Fuse	Rating
Main primary fuse	80A
Electronic motor primary fuse	200A

Base Control Fuses

Figure 55.



F1	F2	F3	F4	F5	F6	F7	F8	F9	F10	F11	F12	F13	F14	F15	F16	F17
1A	10A	15A	5A	5A	10A	10A	5A	20A	15A	10A	5A	3A	3A	5A	7.5A	20A

Table 27.

Fuse ID	Fuse	Rating
F1	Ignition fuse	1A
F2	Base E-stop, horn relay and diagnostic connector	10A
F3	Bosch ECU (Electronic Control Unit) base	15A
F4	Platform weight sensor and tilt sensor	5A
F5	Display and axle lock pressure sensor	5A
F6	Bosch ECU platform supply	10A
F7	Bosch ECU platform supply	10A
F8	Bosch ECU base supply	5A
F9	-	20A
F10	-	15A
F11	Worklight (optional)	10A
F12	-	5A
F13	Liveline	3A
F14	Display	3A
F15	-	5A
F16	Key switch	7.5A
F17	Lift pump	20A

Busbar Fuses

Figure 56.




Table 28.

Fuse ID	Fuse	Rating
FU9	Front motor inverter contactor	500A
FU10	Rear motor inverter contactor	500A
FU11	Pump inverter contactor	250A

Harness Fuses

Figure 57.




Table 29.

Fuse ID	Fuse	Rating
FU1	To chassis ground	10A
FU2	Inverter or recharge relay	10A
FU3	DC-DC converter	20A

Platform Control Fuse

Figure 58.




Table 30.

Fuse ID	Fuse	Rating
F1	Ignition feed fuse	1A

Relays

Primary Relays

Table 31.

Description	Rating
Electric pump relay	150A

Base Control Relays

Figure 59.




Table 32.

Relay ID	Description	Rating
R1	Ignition relay 1	40A
R2	Ignition relay 2	40A
R3	Ignition relay 3	40A
R4	Ignition relay 4	40A
R5	D+ relay	40A
R6	Horn relay	40A

Harness Relays

Figure 60.




Table 33.

Relay ID	Description	Rating
RB6	Precharge relay	40A
RB7	FR/RR inverter relay	20A
RB8	DC-DC converter relay	20A

Platform Control Relay

Table 34.

Relay ID	Description	Rating
R1	Platform buzzer relay	40A

Batteries

California Proposition 65

▲ WARNING Battery posts, terminals and related accessories contain lead and lead compounds, chemicals known to the State of California to cause cancer and birth defects or other reproductive harm. For more information go to www.P65Warnings.ca.gov.

Hydraulic System

General

Table 35.

Description	A45E
Hydraulic tank volume	55L (12UKgal)
Hydraulic system pressure	210bar (3,045.8psi)

Wheels and Tires

General

Table 36.

Tire Size	Type	Make	Tire Width	Tire Outer Diameter	Additional Counter-weight	Category	Remark
33X12D610 (NM)	Foam filled - non-marking	Blacksmith	305mm (12in)	838mm (33in)	130kg (286.60lb)	Standard	130kg (286.60lb) will be company fitted.
33X12-20/7.5 (SR02H) solid	Solid marking	Zhongce Rubber	305mm (12in)	835mm (33in)	130kg (286.60lb)	Option	130kg (286.60lb) will be company fitted.
33X12D610 (Litefoot)	Turf - foam filled marking	Blacksmith	296mm (11 ¹ / ₂ in)	838mm (33in)	210kg (462.97lb)	Option	Remove 130kg (286.60lb) counterweight and assemble 210kg (462.97lb) in place of it.

Fault-Finding

General

Fault code information of the machine is available in help files via servicemaster and service pro.
Refer to: servicepro.jcb.com.

Warranty Information

Service Record Sheet

Table 37.





	Signature and stamp		Date
	Annual Insurance (Yes)		Hours

Figure 61. Installation Checklist





 	 <div> <div></div> <div>/</div> <div></div> <div>/</div> <div></div> </div>  <div> <div></div> <div>h</div> </div>

Figure 62. 1st 100h/1 Month





 	 <div> <div></div> <div>/</div> <div></div> <div>/</div> <div></div> </div>  <div> <div></div> <div>h</div> </div>

Figure 63. 500h/6 Month





 	 <div> <div></div> <div>/</div> <div></div> <div>/</div> <div></div> </div>  <div> <div></div> <div>h</div> </div>

Figure 64. 1000h/12 Month




	 1 / /		h

Figure 65. 1500h/18 Month




	 1 / /		h

Figure 66. 2000h/24 Month




	 1 / /		h

Figure 67. 2500h/30 Month




	 1 / /		h

Figure 68. 3000h/36 Month






		 1	/	/		h
						

Figure 69. 3500h/42 Month





		 1	/	/		h

Figure 70. 4000h/48 Month






		 1	/	/		h
						

Figure 71. 4500h/54 Month





		 1	/	/		h

Figure 72. 5000h/60Month






		 1	/	/		h
						

Figure 73. 5500h/66 Month





		 1	/	/		h

Figure 74. 6000h/72 Month






		 1	/	/		h
						

Figure 75. 6500h/78 Month





		 1	/	/		h

Figure 76. 7000h/84 Month






		 1	/	/		h
						

Figure 77. 7500h/90 Month





		 1	/	/		h

Figure 78. 8000h/96 Month






		 1	/	/		h
						

Figure 79. 8500h/102 Month





		 1	/	/		h

Figure 80. 9000h/108 Month




	 1 / /		h

Figure 81. 9500h/114 Month




	 1 / /		h

Figure 82. 10000h/120 Month







	 1 / /		h

Figure 83. 10500h/126 Month

	 1 / /		h