Maintenance during LOCKDOWN





For Backhoe Loaders and Telehandlers

Parking your JCB

 Park your machine on a level surface.


Cover engine silencer.

Apply a layer of grease on all exposed Ram piston rods.


Battery Care



Use petroleum jelly on battery terminals.




Disconnect terminals to prevent discharge.



Check battery warning indicator status.

Once every 3 Days



Check engine oil level (To be between high and low mark).




Hydraulic Oil level to be visible in gauge.



Start machine for I5-20mins in idle. Operate all gears, steering, brakes, services and stroke all rams in hot condition.

Once every week



Drain water from water separators and check filters.



Check brake fluid level.

> Check tyre inflation pressure.

THANK YOU

#staysafe #stayhome

