

# Maintenance during LOCKDOWN



For Skid Steer Loaders



Always looking  
for a better way

# Parking your JCB

- ✓ Park your machine on a level surface.



- ✓ All cylinders should be closed.
- ✓ Close and lock all access panels.



Always looking  
for a better way

# Parking your JCB

- ✓ **Remove the isolator to avoid battery drain.**




- ✓ **Cover engine silencer.**



**Always looking  
for a better way**


# Every 3 days



**Check the hydraulic oil level**



**Check the Engine oil level**



**Check the Coolant level**



**Always looking for a better way**

# Every 3 days


- ✓ **Clean and remove debris , especially rams, and radiator.**
- ✓ **Install filler caps correctly.**
- ✓ **Start machine for 15-20 mins in idle.**
- ✓ **Move machine forward reverse.**
- ✓ **Stroke all rams in hot condition.**



**Always looking  
for a better way**

# Once every week

Apply a thin layer of grease or petroleum jelly to all the exposed ram piston rods.




Clean the terminal posts with a wire brush or abrasive paper.



Examine tyres and maintain the pressure (4.2Bar).



Drain fuel sedimentary. Do not disconnect the water in fuel connector.



Lubricate the all pivots pins & bushes.



Always looking for a better way

**THANK  
YOU**

**#staysafe  
#stayhome**



**Always looking  
for a better way**